



4-STROKE USE AND MAINTENANCE MANUAL

(MY 25)





4T 250 Fi EN 4T 300 Fi EN 4T 450 Fi EN


4T 250 Fi MX 4T 300 Fi MX 4T 450 Fi MX

4T 250 Fi SMK 4T 450 Fi SMK

4T 450 Fi SMR 4T 450 Fi FT (FLAT TRACK)







The displacement, type of power source and type of use define the model of motorcycle and engine of each TM Racing bike.

The combination of codes 1 and 3 identifies the standard engine type. The combination of the three codes fully identifies the motorcycle model. In this Manual, all 3 codes are usually used to specify the motorcycle model to which certain information refers.

If only codes 1 and 3 are indicated, followed by the word "ALL", it means that the information relates to all motorcycles with the standard engine, regardless of the type of use.

Code 2 (Type of Use) used on its own means that the information refers to all motorcycles with that type of use, regardless of displacement and power source.

All EN/SMR/SMM models are equipped as standard with electric start (E.S.) as well as kick start (K.S.). MX/SMK models have K.S. as standard and may be equipped with E.S. as an option.

Make a note of your motorcycle's serial numbers in the boxes below.

If you contact TM for spare parts, updates or to report any issues, always quote the model, displacement, year of manufacture and, above all, the frame serial number and engine serial number.

FRAME SERIAL NUMBER	
	DEALER STAMP
ENGINE SERIAL NUMBER	
KEY SERIAL NUMBER	

TM reserves the right to make changes without prior notice. Specifications may vary from country to country.

All indications are valid, subject to typos and printing errors.

GENERAL SAFETY REGULATIONS



GENERAL SAFETY REGULATIONS

Read this manual carefully before using your TM motorcycle.

Your safety and that of others depends not just on your riding abilities, but also on your knowledge of the vehicle and how to ride it safely. Do not use the vehicle on public roads or off-road without suitable preparation and apparel.

NOTE: The "Use and maintenance manual" is an integral part of the motorcycle and as such must remain with the vehicle even if it is sold on.

TM reserves the right to make any changes due to further development of its motorcycles. Illustrations are approximate and, in some cases, may not precisely match the part referred to. Reproduction of this publication, even partial, without written authorization is prohibited.

STRUCTURE OF THE MANUAL

The manual is divided into sections and sub-sections.

The following symbols may appear in the text:

▲ DANGER

FAILURE TO COMPLY WITH THIS WARNING MAY LEAD TO SERIOUS INJURY OR DEATH.

▲ DANGER

ALL MAINTENANCE WORK OR ADJUSTMENTS MARKED WITH THE ABOVE SYMBOL REQUIRE TECHNICAL KNOWLEDGE. THEREFORE, FOR YOUR SAFETY, HAVE SUCH OPERATIONS CARRIED OUT ONLY AT A SPECIALIZED TM WORKSHOP, SO THAT YOUR MOTORCYCLE IS SERVICED OPTIMALLY BY SPECIFICALLY TRAINED PERSONNEL.

M WARNING

Failure to comply with that warning could result in damage to parts of the motorcycle or make it unsafe to use.

NOTE: Indicates operations or specific advice about the operation described.



INDICATES THAT THE OPERATION DESCRIBED MUST BE PERFORMED BY A SPECIALIZED TECHNICIAN OR BY A SPECIALIZED TM WORKSHOP.

CARBON MONOXIDE

If maintenance has to be carried out with the engine running, make sure that the work area is well ventilated. Never leave the engine running in enclosed spaces unless they have an extractor system for exhaust fumes.

▲ DANGER

EXHAUST FUMES CONTAIN CARBON MONOXIDE, A POISONOUS GAS THAT CAN CAUSE LOSS OF CONSCIOUSNESS AND DEATH. CARBON MONOXIDE IS ODORLESS AND COLORLESS, MEANING THAT IT CANNOT BE DETECTED BY YOUR SENSE OF SMELL, VISION OR OTHER SENSES. DO NOT UNDER ANY CIRCUMSTANCES INHALE EXHAUST FUMES.

4-STROKE - EN



FUEL

Petrol is toxic. Keep petrol out of the reach of children. Do not use your mouth to siphon petrol. Avoid getting petrol on your skin. If you accidentally get petrol on you, change clothes immediately and use suitable detergents to thoroughly wash the area on which petrol was poured. If you accidentally swallow petrol, do not induce vomiting. Drink plenty of clean water or milk and seek medical advice immediately. If you accidentally get petrol in your eyes, rinse them with plenty of clean cool water and seek medical advice immediately.

A DANGER

THE FUEL USED IN AN INTERNAL COMBUSTION ENGINE IS HIGHLY FLAMMABLE AND MAY CAUSE EXPLOSIONS.

FILL UP WITH FUEL IN A WELL VENTILATED AREA, WITH THE ENGINE OFF.

SMOKING IS FORBIDDEN DURING REFUELING AND IN THE PRESENCE OF FUEL VAPORS.

AVOID CONTACT WITH NAKED FLAMES, SPARKS OR OTHER IGNITION SOURCES THAT COULD MAKE THE FUEL VAPORS CATCH FIRE OR EXPLODE.

PETROL IS A DANGEROUS SUBSTANCE AND MUST NOT BE DISPOSED OF IN THE ENVIRONMENT. ALWAYS USE APPROPRIATE DISPOSAL METHODS, DICTATED BY THE REGULATIONS IN FORCE IN THE COUNTRY WHERE THE PETROL IS USED.

DANGER OF BURNS

A WARNING

During use of the motorcycle, the engine, exhaust system components, cooling system components and braking system components get very hot and remain hot even after the engine has been turned off.

After riding the motorcycle, before touching any part of it, make sure that it has cooled enough to be handled.

COOLANT

▲ DANGER

FIRE RISK: IN SOME CONDITIONS, THE COOLANT IS FLAMMABLE. ITS FLAMES ARE INVISIBLE, BUT CAN CAUSE BURNS.

DO NOT POUR COOLANT ON EXHAUST SYSTEM COMPONENTS OR ON ENGINE COMPONENTS, AS THEY COULD BE HOT AND IGNITE THE COOLANT, WITH THE RISK OF BURNS. REMEMBER THAT THE FLAMES ARE INVISIBLE.

COOLANT MAY CAUSE SKIN IRRITATION AND IS TOXIC IF SWALLOWED.

KEEP COOLANT OUT OF THE REACH OF CHILDREN

COOLANT IS HIGHLY POLLUTING. THEREFORE, AFTER USE, IT MUST BE DISPOSED OF AT SPECIAL COLLECTION CENTERS IN COMPLIANCE WITH REGULATIONS IN FORCE IN THE COUNTRY IN WHICH THE MOTORCYCLE IS USED.

USED ENGINE OIL AND GEARBOX OIL

▲ DANGER

KEEP OUT OF THE REACH OF CHILDREN.

ENGINE OIL AND GEARBOX OIL MAY SERIOUSLY DAMAGE SKIN IF REGULARLY HANDLED FOR LONG PERIODS.

THOROUGHLY WASH YOUR HANDS AFTER HANDLING THE OIL.

WEAR LATEX OR EQUIVALENT GLOVES DURING MAINTENANCE WORK ON THE MOTORCYCLE.

THE OIL IS HIGHLY POLLUTING. THEREFORE, AFTER USE, IT MUST BE DISPOSED OF AT SPECIAL COLLECTION CENTERS IN COMPLIANCE WITH REGULATIONS IN FORCE IN THE COUNTRY IN WHICH THE MOTORCYCLE IS USED.

DO NOT POUR USED OIL INTO DRAINS OR RIVERS. DISPOSE OF FILTERS AT SPECIAL COLLECTION CENTERS IN COMPLIANCE WITH REGULATIONS IN FORCE IN THE COUNTRY IN WHICH THE MOTORCYCLE IS USED.

GENERAL SAFETY REGULATIONS



BRAKE AND CLUTCH FLUID

M WARNING

Brake and clutch fluids are corrosive and can damage painted, plastic or rubber surfaces.

Protect components using a clean cloth when carrying out maintenance on the braking system and the clutch hydraulic system.

Use suitable personal protective equipment, such as gloves and goggles, for maintenance.

If you accidentally get the fluid in your eyes, immediately rinse them with plenty of fresh, clean water and seek medical advice immediately. Keep out of the reach of children.

Brake and clutch fluids are highly polluting. Therefore, after use, they must be taken to special collection centers in compliance with regulations in force in the country in which the motorcycle is used.

LITHIUM IRON PHOSPHATE BATTERY

Motorcycles with electric start are fitted with a lithium iron phosphate (LIFEPO) battery

Lithium batteries are extremely high performance. Lithium iron phosphate cell technology is safe, but that does not prevent improper use of the battery, a short circuit between the poles, overheating, proximity to naked flames or sparks, charging with chargers other than the dedicated ones, from causing serious danger.

▲ DANGER

- DO NOT EXPOSE THE BATTERY TO HEAT OR FIRE OR MICROWAVES; EXPLOSION HAZARD.
- DO NOT EXPOSE THE BATTERY TO TEMPERATURES HIGHER THAN 50°C; EXPLOSION HAZARD.
- DO NOT INSERT METAL OBJECTS IN THE BATTERY HOLDER COMPARTMENT.
- DO NOT PLACE OR CHARGE THE BATTERY AMONGST OTHER METAL OBJECTS (SUCH AS A TOOL BOX) OR WITH OTHER BATTERIES;
 DANGER OF GENERATING SHORT CIRCUITS.
- DO NOT IMMERSE THE BATTERY IN WATER OR OTHER LIQUIDS. DANGER OF SHORT CIRCUIT.
- AFTER REMOVING THE BATTERY FROM THE MOTORCYCLE, PLACE IT OUT OF THE REACH OF CHILDREN.

PROHIBITED OPERATIONS

- NEVER DISCHARGE THE BATTERY TO BELOW 8 V
- DO NOT USE INCOMPATIBLE CHARGERS TO CHARGE THE BATTERY.
- DO NOT USE EXTERNAL JUMPER LEADS NEVER CHARGE A BATTERY THAT IS COMPLETELY DISCHARGED
- DO NOT PUSH START THE MOTORCYCLE IF THE BATTERY IS COMPLETELY DISCHARGED AND THE INSTRUMENT PANEL DOES NOT COME ON.
- DO NOT PIERCE THE BATTERY OR DAMAGE THE CASING.
- DO NOT CONNECT MORE THAN ONE BATTERY TO THE MOTORCYCLE ELECTRICAL SYSTEM.
- DO NOT CONNECT THE BATTERY WITH INVERTED POLES.

RECOMMENDED OPERATIONS

- USE A COMPATIBLE BATTERY CHARGER OR A MAINTAINER.
- CONNECT THE MOTORCYCLE TO THE MAINTAINER IF YOU WILL NOT BE RIDING IT FOR LONGER THAN 7 DAYS. ALTERNATIVELY, DISCONNECT THE MOTORCYCLE BATTERY.
- CHECK THAT THE CHARGING SYSTEM ON THE MOTORCYCLE IS ALWAYS OPERATIONAL.
- CHECK THAT THE VOLTAGE SUPPLIED BY THE CHARGE CONTROLLER IS BETWEEN 13.8 V AND A MAXIMUM OF 14.6 V.





DISPOSAL

Used batteries must be taken to a collection center specializing in separate disposal, in compliance with regulations in force in the country in which the motorcycle is used.

Batteries must not be mixed with domestic or industrial waste.

TRANSPORTING THE MOTORCYCLE

A WARNING

- When transporting your TM motorcycle, make sure that it is secured in an upright position using straps or other mechanical fixing devices, to be fixed on sturdy parts of the motorcycle such as the handlebar, forks, large swing arm, etc.
- Do not secure the motorcycle by attaching straps or the like to the plastic panels.
- If the motorcycle falls, petrol could leak out, posing serious risks.

TYPE APPROVAL (EN-SMR)

All versions are approved to be used by the rider only; transporting a passenger is forbidden.





IMPORTANT WARNINGS

TM sport motorcycles are designed and built to withstand stresses causes by normal road and competition use. Competition motorcycles comply with the rules of the respective categories currently in force at the leading international motorcycle associations.

Strict compliance with the checking, maintenance and calibration instructions for the engine and chassis indicated in this manual is essential for good operation and to prevent premature wear of motorcycle parts. Incorrect engine or chassis calibration may also compromise your safety and the safety of others.

Maintenance operations described in the "Maintenance schedule" must be carried out by a TM specialized workshop at the scheduled intervals, otherwise the warranty will be null and void.

If you contact TM for spare parts, updates or to report any issues, always quote the model, displacement, year of manufacture and, above all, the frame serial number and engine serial number.

Use the fuels and lubricants indicated in the use and maintenance manual as described in the maintenance schedule. Products of different brands may be used provided that they have equivalent specifications.

<u>In the event of direct and consequential damage</u> caused by tampering with or modification of the motorcycle, the warranty is null and void.

Using the motorcycle under extreme conditions, e.g.: on very muddy and wet terrain, may cause excessive wear on components such as transmission parts or brakes. Therefore, maintenance or replacement of some parts may be necessary sooner than the normal interval indicated in the maintenance schedule.

USE OF ALL MX / SMK / FT MODELS IS NOT ALLOWED ON PUBLIC ROADS

If approved models are modified or tampered with in a way that changes their basic characteristics, their approval will no longer be valid.

All EN models are designed for use off-road (Enduro) and are not suitable for Motocross.







		Page
Red	cognizing tm racing motorcycle models	3
	neral safety regulations	
	ucture of the manual	
	rbon monoxide	
Fue	-	
	nger of burnsolant	
	ed engine oil and gearbox oil	
	ake and clutch fluid	
Lith	hium iron phosphate battery	6
	ohibited operations	
	commended operations	
	sposal	
	ansporting the motorcyclePE APPROVAL (EN-SMR)	
	PORTANT WARNINGS	
1.		_
	Frame serial number	
	Version Serial number	
	Engine serial number	
	Engine serial number	1-17
2.	CONTROL COMPONENTS	2•19
	Right-hand side main components topography	
	Left-hand side main components topography	
	Hydraulic clutch lever	
	BREMBO pump front brake lever	2•23
	BREMBO radial pump front brake lever (SMR)	
	BREMBO 16x18 radial pump front brake lever (SMK)	
	Throttle	
	Combination switch (EN)	
	Double mapping switch (optional)	
	Starter switch (SMR)	
	Start engine button (MX E.S. / SMX E.S. / EN)	
	Engine stop button (MX / SMK)	
	Cold start device (250 - 300 EN-SMR / MX / SMK)	
	Choke lever (SMR/EN 450)	
	Choke lever (450 MX/SMX)	2•27
	Digital electronic speedometer and indicators (EN / SMR)	2.20
	Display	
	Functions	
	Gear shifting pedal	
	Kick starter	
	Rear brake pedal	
	Steering lock (EN/SMR)	
	Fuel tank	
	Side stand Idle adjustment knob	
	idle adjustment knob	2•39
3.	INSTRUCTIONS FOR USE	3•41
٠.	Indications for first use	_
	Safety regulations	
	Running-in instructions	
	Preliminary checks	3•44
	Mounting/dismounting of rider	
	Adjusting the rear-view mirrors	
	Start-up of the motorcycle with electrical starter	
	Kick start of the motorcycle	
	Cold start	3•48

	Kick start in the event of a fall	3•50
	Start with flooded engine	3•50
	Setting off	3•50
	Accelerating, shifting gears, slowing down	3•51
	Braking	3•51
	Stopping and parking	3•52
	Washing	3•53
	Precautions for winter use	3•53
	Storage	3•54
	Start-up after winter	3•54
4.	MAINTENANCE	4•5
	MX 250 - 300 ES FI MAINTENANCE TABLE	4•57
	MX 250 - 300 ES Fi / SMK 250 MAINTENANCE TABLE	4•59
	EN - SMR 450 ES FI MAINTENANCE TABLE	4•61
	MX - SMK 450 ES FI MAINTENANCE TABLE	
	Fork compression adjustment	4•65
	ADJUSTING THE STROKE	4•65
	Standard adjustment	4•65
	Fork rebound adjustment	4•66
	Adjusting the stroke	
	Standard adjustment	
	Varying pre-load and replacing fork springs	4•67
	Bleeding the telescopic fork	4•67
	Cleaning telescopic fork dust seal	4•68
	Shock absorber compression adjustment	4•68
	Adjusting the stroke	4•68
	Standard adjustment	4•68
	Adjusting the stroke	4•69
	Standard adjustment	4•69
	Shock absorber rebound adjustment	4•69
	Adjusting the stroke	
	Standard adjustment	4•69
	Varying pre-load and replacing shock	
	Absorber spring	4•70
	Basic suspension calibration depending on the	
	Weight of the rider	
	Adapting fork basic calibration	
	Adapting shock absorber basic calibration	
	Checking shock absorber static sag	4•72
	CHECKING shock absorber rider SAG	
	Checking steering bearings and play adjustment	
	Rear suspension linkage	
	Checking chain tension	
	TENSIONING the chain	4•75
	Chain maintenance	4•75
	Chain wear	
	HYDRAULIC CLUTCH PUMP	
	Checking AND TOPPING UP the HYDRAULIC fluid level	4•77
	Bleeding the hydraulic clutch	
	Basic indications for TM disc brakes	4•78
	BREMBO front brake PUMP	
	Topping up brake fluid	
	BREMBO RADIAL front brake PUMP (SMR)	
	BREMBO 16x18 RADIAL front brake PUMP (SMK)	
	Changing basic position of rear brake pedal	
	Checking Rear brake fluid level	
	Checking front brake pads	4•85
	Checking rear brake pads	4•86
	Replacing front brake pads	4•87
	Replacing rear brake pads	
	Disassembling and assembling front wheel	4•89
	Disassembling and assembling rear wheel	
	(EN/MX/SMR/SMK)	4•90

CONTENTS



	Checking spoke tension	
	Tire pressure	4•91
	Checking SPEEDOMETER magnetic sensor distance	
	(EN/SMR)	4•92
	Removing the seat	
	Removing the airbox	
	Battery	
	Charging THE battery	
	DIODE	
	Recharge fuse	
	Accessory fuse (EN/SMR)	
	Adjusting the height of the front headlamp	
	Led headlight for models (en/smr)	
	Replacing front headlight	
	LED taillight (EN/SMR)	
	turn signal (EN/SMR)	4•98
	Cooling	4•99
	Draining, filling and bleeding the cooling system	4•100
	Replacing exhaust silencer packing material	
	Cleaning air filter	
	CHOKE (450 SMR/EN)	
	Adjusting THROTTLE control CABLES	
	Adjusting idle speed	
	Oil circuit (250 - 300)	
	Oil circuit (450)	
	Engine oil	
	Checking engine oil level (250 - 300)	
	Checking engine oil level (450)	
	Changing engine oil and filter (250 - 300)	
	Changing engine oil and filter (450)	4•109
5.	DIAGNOSIS	5•111
	Connecting obd tool	5•116
	Caltool Manual	5•117
	Software user guide	5•121
	-	
6.	TECHNICAL DATA	6•129
	ENGINE TECHNICAL DATA EN - SMR 250 - 300 - 450	6•131
	TECHNICAL DATA ENGINE MX 250 - 300 - 450	
	TECHNICAL DATA ENGINE SMK 250 - 300 - 450	
	TECHNICAL DATA - ENGINE FT 450	
	CHASSIS TECHNICAL DATA EN 250 - 300 - 450	
	CHASSIS TECHNICAL DATA SMR 250 - 300 - 450	
	CHASSIS TECHNICAL DATA MX 250 - 300 - 450	
	CHASSIS TECHNICAL DATA SMK 250 - 300 - 450	
	CHASSIS TECHNICAL DATA FT 450	6•137
	Tightening torques	
	Engine tightening torques	6•138
	Lubrication	6•139
7.	WIRING DIAGRAMS	7•141
-	ENGINE WIRING DIAGRAM (250-300-450-530 EN)	
	ENGINE WIRING DIAGRAM (530-450 SMR)	
		, 177
R	ALPHABETICAL INDEX	8.145



1. VEHICLE IDENTIFICATION

2. CONTROL COMPONENTS

3.	INSTRUCTIONS	FOR
		USE

4. MAINTENANCE

5. DIAGNOSIS

6. TECHNICAL DATA

7. WIRING DIAGRAMS

13





1. VEHICLE IDENTIFICATION







4-STROKE - EN —






FRAME SERIAL NUMBER


The frame serial number (1) is stamped on the right-hand side of the steering head.

Write this number in the space provided.

The serial number is also shown on a data plate (2) located on the left-hand side for EN / SMR / SMM models.

VERSION	SERIAL NUMBER
4T - 250 AJE END 250	TM MOTO S.R.L. L3e-A2E e24*168/2013*00028 ZEX250AJETMMP0000 85 db (A) - 2750 min ⁻¹ 9,8 kW max 253 kg
4T - 300 AJE END 300	TM MOTO S.R.L. L3e-A2E e24*168/2013*00026 ZEX300AJETMMP0000 86 db (A) - 3750 min ⁻¹ 9,8 kW max 252 kg
4T - 450 AJE END 450	TM MOTO S.R.L. L3e-A2E e24*168/2013*00029 ZEX450AJETMMP0000 86 db (A) - 3375 min ⁻¹ 10,6 kW max 305 kg
4T - 450 AJM SMR 450	TM MOTO S.R.L. L3e-A2E e24*168/2013*00029 ZEX450AJMTMMP0000 86 db (A) - 3375 min ⁻¹ 10,6 kW max 305 kg






ENGINE SERIAL NUMBER

The engine serial number (1) is engraved on the back of the engine, near the shock absorber.

Write this number in the space provided at the start of the manual.
















4-STROKE - (EN) -



RIGHT-HAND SIDE MAIN COMPONENTS TOPOGRAPHY

- 1 Throttle
- 2 Front light (EN SMR)
- 3 Front indicator lights (EN SMR)
- 4 Front wheel
- **5** Front suspensions
- 6 Exhaust manifold
- 7 Rear brake pedal
- 8 Engine
- 9 Kick start lever (OPT)
- 10 Pump with rear brake oil tank
- 11 Exhaust silencer
- 12 Rear wheel
- **13** Rear brake disc
- **14** Rear brake caliper
- 15 Right radiator
- **16** Radiator cap
- 17 Front brake lever with oil tank
- 18 Fuel tank cap
- 19 Fuel tank




2•21



29 19

LEFT-HAND SIDE MAIN COMPONENTS TOPOGRAPHY

- 1 Front brake disc
- 2 Front brake caliper
- 3 Left radiator
- 4 Voltage regulator
- 5 Left-hand grip
- 6 Horn (EN SMR)
- 7 Engine startup button
- 8 Double mapping switch (optional)
- 9 Left switch (EN SMR)
- Engine switching off button (MX SMK)
- 10 Clutch lever with oil tank
- 11 Throttle body
- 12 Gearbox system lever
- 13 Kickstand
- 14 Secondary transmission chain
- **15** Crown
- 16 Rear indicator lights (EN SMR)
- 17 Rear light/licence plate light (EN SMR)
- **18** Seat
- 19 Battery
- 20 Air filter
- 21 Instrument
- 22 Key switch SMR
- 23 Rear shock absorber



26

24 ECU

28 Relay

Diode

Ignition contactor

27 Light system fuse


Contactor fuse

24

25

26

29







HYDRAULIC CLUTCH LEVER


The Brembo clutch pump (1) is located on the left-hand side of the handlebar.

The clutch lever (2) detaches the transmission from the engine.

To operate the clutch, pull the lever towards the grip as far as it will go.

The position of the lever relative to the grip can be altered to suit the rider.

See the "Maintenance" section.




BREMBO PUMP FRONT BRAKE LEVER

The Brembo front brake pump (1) is located on the right-hand side of the handlebar.

The front brake lever (2) applies the front wheel brake.

The position of the front brake lever relative to the grip can be altered to suit the rider.

See the "Maintenance" section.




BREMBO RADIAL PUMP FRONT BRAKE LEVER (SMR)

The Brembo radial front brake pump (1) is located on the right-hand side of the handlebar.

The front brake lever (2) applies the front wheel brake.

The position of the front brake lever relative to the grip can be altered to suit the rider.

See the "Maintenance" section.



BREMBO 16X18 RADIAL PUMP FRONT BRAKE LEVER (SMK)

The Brembo radial front brake pump (1) is located on the right-hand side of the handlebar.

The front brake lever (2) applies the front wheel brake.

The position of the front brake lever relative to the grip can be altered to suit the rider.

2•23

See the "Maintenance" section.






THROTTLE

The throttle control (1) is located on the right-hand side of the handlebar.

To increase the power supplied by the engine (accelerate), turn the grip (2) towards you. To reduce power, turn the grip away from you.

Make sure that the grip always has 1-2 mm of play.

See the "Maintenance" section.



LIGHT SWITCH (EN)

The light switch (1) is located near the left handle of the handlebar.

Its operation is very intuitive.


The low-beam lights light up upon ignition of the motorcycle, move the switch (2) in correspondence of the symbol " \equiv " to switch on the high-beam headlight.

Press the key (3) to activate the buzzer.

Move the lever (4) to the left to activate the left direction indicator, or to the right to activate the right direction indicator. The lever (4) returns to central position.

Press the lever (4) to deactivate the direction indicator.

Press the button (5) to switch off the engine.









DIMMER SWITCH (SMR)

The dimmer switch (1) is located on the handlebar near the left-hand grip.

Its is traditional and simple to use.


Button (2) sounds the horn, whilst pressing button (3) to the left activates the LH turn signal, and to the right activates the RH turn signal.


Press the button to the center to switch off the turn signals.

The red button (4) selects low or high beam:

- pushed in: high beam;
- · out: low beam.

Button (5) is for flashing the high beam.






DOUBLE MAPPING SWITCH

These motorcycles versions are equipped with an engine mapping switch (1).

- If the switch is pressed in position (1a), it activates Map "1" for a "Full power" driving of the motorcycle.
- If the switch is pressed in position (1b), it activates Map "2" for a "Soft" driving of the motorcycle.
- It is possible to switch from a Full power driving to a Soft driving and vice versa while driving the motorcycle.



2•25



STARTER SWITCH (SMR)

Models equipped with a battery and electric start have a control with two buttons, one red (1) and one black (2), next to the throttle.

The red button (1) has two positions.

When pushed in, it prevents the engine from starting. The engine does not start even with the kick starter.





With the button pushed in, engine starting is disabled.

NOTE: If the button is pushed when the engine is running, the engine does switch off.






With the button in the "out" position, engine starting is enabled.



- The black button (2) activates the starter motor.
- Set the gear control to "neutral", then press to start the engine and release as soon as the engine is running.
- Only use this control for a maximum of 3 seconds at a time, then wait another 5 seconds before trying again.

NOTE: Use the manual air lever to help.

- After 3 or 4 attempts stop and look for possible problems.
- Never press this button while the engine is running.



START ENGINE BUTTON (MX - SMK - EN)

The start engine button (1) is located near the right-hand handlebar grip.

- Set the gear control to "neutral", then press the button to start the engine and release it as soon as the engine is running.
- Only use this control for a maximum of 3 seconds at a time, then wait several seconds before trying again.
- After 3 or 4 attempts stop and look for possible problems.
- Never press this button while the engine is running.








ENGINE STOP BUTTON (MX / SMK)

Keep the off button pressed (1), which is located near the left-hand grip on the handlebar.

 Press this button to switch off the engine and release it as soon as the engine is off.



KEY IGNITION / OFF SWITCH (SMR)

SMR models have a cylinder (1) for the ignition key on the side of the dashboard.

- To enable engine starting, put the key in the cylinder (1) and turn it clockwise from the "\overline{\textit{N}}" symbol to the "\overline{\textit{N}}" symbol.
- To switch off the engine, turn the key anti-clockwise from the "
 " symbol to the "
 " symbol: the position in which the key can be removed.



COLD START DEVICE (250 - 300 EN-SMR /MX/SMK)


This vehicle provides for a cold start device positioned on the throttle body.

- To activate the cold start device, pull the knob (1) externally, the knob remains in extracted position.
- After the vehicle start, wait a few seconds until the engine speed stabilizes (depending on ambient temperature), then disable the cold start device by moving the knob (1) to its initial position.

A WARNING

ONLY activate the cold start device when the engine is switched off and cold. NEVER activate it during motion.

Use the cold start device only if necessary.




CHOKE LEVER (SMR/EN 450)

The choke lever (1) is located on the left-hand side of the handlebar, on the clutch pump.

- Activating this lever makes it easier to start the engine under certain conditions.
- To activate it, pull it all the way down and keep it in that position until the engine starts.


The choke is turned off automatically when the lever is released.





DIGITAL ELECTRONIC SPEEDOMETER AND INDICATORS (EN / SMR)

The digital speedometer consists of a large backlit display and a set of indicators.



Legend of indicators and buttons:

- 1) Backlit display.
- 2a) GREEN left turn signal indicator.
- 2b) GREEN right turn signal indicator.
- 3) BLUE high beam ON indicator.
- 4) NOT USED.
- 5) AMBER fuel reserve indicator.
- 6) ORANGE engine fault indicator.

If the indicator remains on while using the motorcycle, contact a TM dealer as soon as possible.

7) "Select" button.

Press the button to select the following functions:

- Time
- Stopwatch.
- · Maximum speed record.


8) "Adjust" button

Press the button to view:

- Odometer;
- Trip "A" partial km/miles;
- Trip "B" partial km/miles;
- Total hours counter;
- Partial hours counter "A";
- Partial hours counter "B".



DISPLAY



Display legend:

1) Speed indicator

Shows the vehicle speed. The top speed is 360 km/h - 225 mph.

Use the "Select" button to switch between speed in km/h or mph.

2) Odometer / "Trip" partial counters

This part of the display can be used to see the total km/miles travelled or partial km/miles travelled on the "Trip A" or "Trip B" counter. To show the various functions, use the "Adjust" button.

Odometer

- Indicates total km/miles travelled.
- Maximum value is 99999 km/miles. When that maximum has been reached, the counter is reset and starts again from "0".
- Minimum record is 1 km/mile.

• "Trip" partial km/miles counters

Two partial counters, "Trip A" and "Trip B" can be set. Indicates the partial km/miles travelled. Maximum value is 9999.9 km/miles. When that maximum has been reached, the counter is reset and starts again from "0". Minimum record is 0.1 km/mile.

3) Clock / Stopwatch / Maximum speed

This area of the display can show the time, the stopwatch and the maximum speed reached. Use the "Select" button to access the various functions.

• Time

The time can be displayed in 12 or 24 hour format.

Stopwatch

The stopwatch can be displayed, set to automatically start when the wheel begins turning and to stop when the wheel stops turning.

• Average speed / maximum speed

- The average speed can be displayed.
- The maximum speed reached can be displayed.
- The top speed is 360 km/h 225 mph.

4) Battery status

The battery status is displayed;

= fully charged

= discharged, needs replacing.




FUNCTIONS


Partial km / miles selection




Starting on the home screen page, press the "Adjust" button once to switch from the odometer function (total km / miles travelled) to the "Trip A" partial km / miles travelled function.



From "Trip A" press the "Adjust" button to go to the "Trip B" partial km/miles travelled function.



To reset the km/miles travelled both in "Trip A" and in "Trip B" with the function active press the "Adjust" button for three seconds



Km / Miles unit of measurement setting

Starting on the home screen page, with the ODO function set, press the "Adjust" button for three seconds to change the unit of measurement from km to miles, from km/h to mph and vice versa.



2•30


4-STROKE - EN




Hours counter selection

The instrument can count total hours of engine operation and partial hours of operation "A" and "B".


- Display the "Trip B" section, then press the "Adjust" button once to display the total hours of engine operation (value cannot be reset).




Press the "Adjust" button to switch from the total hours of engine operation to the partial hours of operation "A".




From "A" press the "Adjust" button to switch to the display of partial hours "B".



To reset the partial hours of operation both in "A" and in "B" with the function active press the "Adjust" button for three seconds.




To return to the home screen page press the "Adjust" button.





Setting the clock to 12 or 24 hour format



From the time home screen page, press the "Select" button from 3 seconds to change the clock display from 12 to 24 hour format or vice versa.

NOTE: When the clock is set to the 12 hour format, AM (morning) or PM (afternoon) will appear at the top.

Stopwatch





From the home screen page press the "Select" button to switch from the clock to the stopwatch.

NOTE: The stopwatch starts when the wheel begins turning and stops when the motorcycle comes to a stop; or you can press the "Select" button to start it.

To stop the stopwatch, press the "Select" button again.

To reset the stopwatch, press the "Select" button for 3 seconds.



Display average speed / maximum speed

Set the stopwatch function, then press the "**Select**" button to display the maximum speed and the average speed. The display shows "**AVG**" and the top speed and average speed alternate onscreen every three seconds.



To reset the maximum speed and average speed, press the "Select" button for three seconds.



2•32

To return to the home screen page, press the "Select" button.

4-STROKE - (EN)



Setup

To open the "Setup" menu, simultaneously press the "Select" and "Adjust" buttons for several seconds.

You can use this menu to set the following functions:

· Wheel circumference and sensor setup



• Time



Stopwatch start



• Odo



NOTE: To move from one setting to another, press the "Select" button.

Setting the wheel circumference and sensor setup

Depending on the models, the following values must be set:

MODEL	CIRCUMFERENCE	SENSOR SETUP
EN	2205	04
SMR	2060	04

Set the wheel circumference and the sensor setup as follows:

From the home screen page simultaneously press the "Adjust" and "Select" buttons for three seconds to enter setup mode. The following screen page appears on the display:





Press the "Adjust" button and the following screen page appears on the display:



The editable value flashes;

for example, to set the circumference value "2130" and the sensor setup "04", proceed as follows:


- press the "Setup" button twice to set the first number to "2";
- press the "Adjust" button to move to the second editable number and press the "Setup" button once to set the number to "1";
- press the "Adjust" button to move to the third editable number and press the "Setup" button three times to set the number to "3";
- press the "Adjust" button to move to the fourth editable number. In this case, do not press the "Setup" button, as the number to be set is "0";



- press the "Adjust" button to set the sensor setup and the following screen page appears:



- in this case do not press the "Setup" button, as the number to be set is "0";
- press the "Adjust" button to move to the second editable number and press the "Setup" button four times to set the number to "4";



After several seconds of inactivity, the program automatically exits the setup mode and returns to the home screen page.

• Time setting

To set the time, proceed as follows:

Press the "Adjust" and "Select" buttons simultaneously for three seconds to enter setup mode. The following screen page appears on the display:






Press the "Select" button and the following screen page appears on the display:




Press the "Adjust" button and the following screen page appears on the display:



The hours value flashes. To set the hours, for example 14, press the "Setup" button as many times as needed to reach the desired hours number.

NOTE: Set the time according to the 12 or 24 hour format selected.



Press the "Adjust" button to move to the minutes setting. The following screen page is displayed:



The minutes value flashes. To set the minutes, for example 5, press the "**Setup**" button as many times as needed to reach the desired number of minutes.

NOTE: The minutes can be set from 0 to 59.





Press the "Adjust" button to return to the clock setting screen page:



Press the "Adjust" and "Select" buttons simultaneously for three seconds to exit the setup mode and return to the home screen page.



• Stopwatch

The stopwatch has been set to work automatically. It starts when the motorcycle begins moving and stops when the motorcycle comes to a stop.

NOTE: The default setting must not be changed. If necessary, go to the setup mode and check that its operation is set to "AUTO".

Odo

This function is not active.

NOTE: The default setting must not be changed. If necessary, go to the setup mode and check that operation is set to "OFF".





GEAR SHIFTING PEDAL

The gear shifting pedal (1) is fitted on the left side of the engine.

The position of the gears is shown in the illustration.

Neutral is between first gear and second gear.

- To engage first gear, pull the clutch lever and press the gear shifting pedal downwards.
- To engage the other gears, pull the clutch lever and push the gear shifting pedal upwards.





KICK STARTER (OPT)

The kick starter (1) is on the right side of the engine.

Once in "neutral", rotate the pedal outwards and use your foot to start the engine with it.

For EN/SMR models, make sure that the button is out, as described in the relative paragraph, before starting the engine.

For SMR models, make sure that the button is out and turn the key, as described in the relative paragraph, before starting the engine.

For all other models, simply use the pedal to start the engine.



Starting from the highest position, push the starter all the way down with fast, continuous movements.


Once the engine has started, fold the pedal in again.

REAR BRAKE PEDAL

The brake pedal (1) is located in front of the right-hand footrest.

The basic position can be adjusted to suit the rider.

See the "Maintenance" section.



STEERING LOCK (EN/SMR)

The steering lock (1) is on the left-hand side of the steering head.

This device allows you to prevent rotation of the handlebar, so that the motorcycle cannot be ridden.

 To lock the steering, turn the handlebar all the way to the right, move the protective tab (2), insert the key, turn it to the left and press it all the way down. Keeping it pressed down, turn it to the right and remove it.



When you have unlocked the steering, do not leave the key in the lock. If you steer left, the key could bend or break.



2 • CONTROL COMPONENTS



FUEL TANK

The fuel cap (1) is at the top of the fuel tank, in the rear right area of the motorcycle.

- To open it: unscrew the tank cap by turning it anti-clockwise.
- To close it: place the tank cap in the filler neck and turn it clockwise.

TM engines use super unleaded fuel (E5) - (E10).

E5 = Petrol containing up to 5% of ethanol in proportion to its volume. E10 = Petrol containing up to 10% of ethanol in proportion to its volume.

Tank capacity:

I 7.2 total, of which 2.2 is reserve

A WARNING

Fill the tank with unleaded petrol with a minimum octane number of 95. Never use petrol with octane lower than 95, as it could damage the engine. Fuel expands when heated. Therefore, in high temperatures, do not fill the tank to the top.

▲ DANGER

PETROL IS HIGHLY FLAMMABLE AND TOXIC. HANDLE PETROL WITH EXTREME CARE. DO NOT FILL-UP WITH PETROL NEAR NAKED FLAME OR LIT CIGARETTES. ALWAYS TURN OFF THE ENGINE BEFORE FILLING UP WITH PETROL. TAKE CARE NOT TO GET PETROL ON THE ENGINE OR ON THE EXHAUST PIPE. IMMEDIATELY REMOVE ANY SPILT PETROL WITH A CLOTH. IF PETROL IS SWALLOWED OR GETS IN YOUR EYES, SEEK MEDICAL ADVICE IMMEDIATELY.



SIDE STAND

Use your foot to move the side stand (1) forward until it stops, then lean the motorcycle onto it.

Make sure that the ground is solid and the parking position is stable. For greater safety, engage 1st gear with the engine off.

When you lift the motorcycle, the side stand automatically lifts up.

M WARNING

The side stand is only designed to support the weight of the motorcycle. Never sit on the motorcycle while it is resting on the side stand, as the side stand may be damaged and the motorcycle may fall over.







IDLE ADJUSTMENT KNOB

The idle speed adjustment knob (1) is on the left-hand side of the motorcycle.

Turn the idle knob to raise or lower the engine idle speed.







4-STROKE - (EN) -



3. INSTRUCTIONS FOR USE







3•42

4-STROKE - EN



INDICATIONS FOR FIRST USE

- Make sure that the motorcycle's "PRE-DELIVERY OPERATIONS" have been completed by your TM dealer.
- Carefully read all of the instructions before using the motorcycle for the first time.
- Familiarize yourself with all of the controls.
- Adjust the clutch lever, the front brake lever and the brake pedal to the most comfortable position.
- Practice riding the motorcycle in an empty car park or on easy terrain before going for a long drive. Also try standing up while riding slowly, to get a feel for how the motorcycle handles.
- Do not choose routes that are too difficult for your skill level and experience.
- Hold the handlebar with both hands and keep your feet on the footrests.
- Make sure you do not press the brake pedal with your foot if you do not want to stop. If the brake pedal is not released, the brake pads rub continuously causing the brake to overheat.
- Do not make changes to the motorcycle and always use TM ORIGINAL SPARE PARTS. Spare parts from other manufacturers may affect the safety of the motorcycle.
- Motorcycles are sensitive to shifts in weight distribution. Luggage must be fastened near the center of the motorcycle and its weight must be evenly distributed between the front and rear wheels.
- Follow the running-in instructions.

M WARNING

Although EN models have approval, they must be driven with care on roads. Above all, avoid long stretches with wide open throttle.

SAFETY REGULATIONS

▲ DANGER

- ALWAYS WEAR SUITABLE CLOTHES WHEN USING THE MOTORCYCLE. WISE BIKERS WHO RIDE A TM ALWAYS WEAR APPROVED HELMET, BOOTS, GLOVES AND JACKET, BOTH FOR LONG JOURNEYS AND SHORT DISTANCES. PROTECTIVE GEAR SHOULD BE HIGHLY VISIBLE TO ALLOW OTHER DRIVERS ON THE ROAD TO SEE THE BIKER IMMEDIATELY.
- DO NOT DRIVE AFTER CONSUMING ALCOHOL.
- ALWAYS USE TM ORIGINAL ACCESSORIES. FOR EXAMPLE, FRONT COVERINGS MAY AFFECT MOTORCYCLE PERFORMANCE AT HIGH SPEED.
 EVEN LUGGAGE, ADDITIONAL TANKS, ETC. MAY AFFECT MOTORCYCLE PERFORMANCE DUE TO THE DIFFERENT WEIGHT DISTRIBUTION.
- BOTH THE FRONT AND THE REAR WHEELS MUST BE FITTED WITH TIRES WITH THE SAME TYPE OF PROFILE.
- AFTER THE FIRST 30 MINUTES OF RIDING, YOU MUST CHECK THE TENSION OF THE SPOKES. SPOKE TENSION DECREASES RAPIDLY ON NEW WHEELS. IF YOU KEEP RIDING WITH LOOSE SPOKES, THEY MAY BREAK, CAUSING INSTABILITY (SEE CHECKING SPOKE TENSION).
- ALL EURO 4 MODELS ARE DESIGNED AND SET UP FOR ONLY 1 RIDER. CARRYING A PASSENGER IS PROHIBITED.
- COMPLY WITH TRAFFIC REGULATIONS AND DRIVE WITH CAUTION SO AS TO RECOGNIZE DANGER AS SOON AS POSSIBLE.
- ADJUST THE SPEED OF THE VEHICLE ACCORDING TO THE CONDITIONS OF THE ROAD AND YOUR DRIVING SKILLS.
- DRIVE WITH CAUTION ON UNKNOWN ROADS OR TERRAINS.
- WHEN GOING OFF ROAD, ALWAYS GO WITH A FRIEND WITH A SECOND MOTORCYCLE, SO YOU CAN HELP EACH OTHER IF NECESSARY.
- PROMPTLY REPLACE THE VISOR OR LENSES OF YOUR GLASSES. SCRATCHED VISORS OR GLASSES MAKE IT NEARLY IMPOSSIBLE TO SEE IN POOR LIGHT CONDITIONS.

3•43

- NEVER LEAVE THE MOTORCYCLE UNATTENDED WITH THE ENGINE RUNNING.

▲ DANGER

- ONLY EN AND SMR MODELS HAVE APPROVAL FOR USE ON PUBLIC ROADS OR MOTORWAYS.
- WHEN RIDING YOUR MOTORCYCLE, ALWAYS BEAR IN MIND THAT LOUD NOISE MAY DISTURB OTHER PEOPLE.

3 • INSTRUCTIONS FOR USE



RUNNING-IN INSTRUCTIONS

The component surfaces of a new motorcycle, despite precision machining, are not as smooth as the components of motorcycles that have been running for a long time. This is why running-in a new motorcycle is so important.

For optimal settling of moving parts, a new motorcycle must be brought to its maximum performance gradually.

The main rules to follow are:

- 1. After cold start, warm up the engine for about 1 minute before starting to use the motorcycle.
- 2. During the first 3 hours of use (1 hour for competitive use) the engine must be used only up to a maximum of 50% of its power. Plus, the number of revs must not exceed 9000 rpm for 250cc or 300cc engines and 6000 rpm for 450 cc engines.
- 3. During the subsequent 5 hours of use (1 hour for competitive use) the engine can be used up to a maximum of 75% of its power. Ride the motorcycle under a variety of conditions (road, easy off-road stretches). Do not go on long journeys without ever closing the throttle. Gradually increase and reduce throttle opening, alternating acceleration and deceleration with short periods at constant speed. Make sure that the coolant does not reach temperatures that are too high (indicated by fluid leaking from the bleeder hose).

By following these rules, you will obtain maximum performance and longer engine life.

It is essential that you carry out the operations described in the "Maintenance Schedule" during the running-in period.

Be particularly careful when replacing the oil and cartridge filter, as metal particles that can detach from the surfaces of engine parts in contact during running-in circulate in the oil and are deposited in the filter. Therefore, replacing the oil and the filter allows these particles to be definitively removed from the engine.

PRELIMINARY CHECKS

In order to drive safely, the motorcycle must be in good condition and well maintained. It is good practice to perform a general check on the motorcycle before every use.

It must include the following checks:

- fuel level and engine oil level check;
- brake fluid level check;
- coolant level check;
- brakes correct operation check;
- brakes pipes and pads condition check;
- steering check, turning handlebar all the way in both directions;
- tires pressure and condition check;
- chain tension check;
- flexible cable controls check and adjustment if necessary;
- if carrying luggage, check that it is secured.
- Start the engine: check that the instrument display lights up and;
- turn on the high beam and check that the relative indicator comes on;
- activate the turn signals and check that the relative indicators come on;
- check that the rear brake light comes on;
- check that the horn works;
- check that after starting the "("Engine fault" indicator does not come on.

N.B.: For checks and any adjustments necessary, see the Maintenance section.





MOUNTING/DISMOUNTING OF RIDER

Carefully read the instructions below as they provide important information for rider safety and to prevent harm to persons or damage to the motorcycle.

The motorcycle must always be mounted or dismounted from the left-hand side with your hands free, no obstacles in the way and with the stand down.

Do not get off the vehicle by jumping or extending your legs and always dismount by following the instructions given in the relevant section.

MOUNTING OF RIDER

With the motorcycle on the side stand, do the following:

- From the left side, hold the handlebar correctly with both hands and extend your right leg over the saddle.
- Sit on the motorcycle and place both feet on the ground. Balance the vehicle without putting all your weight on the side stand.

M WARNING

If you are unable to place both feet on the ground, put your right leg down with your left leg poised.

- Start the motorcycle as described in the relevant section.
- Use your left foot to check that the stand has completely retracted.


DISMOUNTING THE MOTORCYCLE


- Stop the vehicle and switch off the engine.

A WARNING

Make sure that the area where you want to park the vehicle is stable and level.

- Place both feet on the ground.
- Switch off the motorcycle as described in the relevant section.
- Using your left leg, fully extend the stand.
- Tilt the motorcycle to the left until it rests on the stand.
- Firmly grasp the handlebar and dismount on the left-hand side by lifting your right leg.





ADJUSTING THE REAR-VIEW MIRRORS

Sit on the motorcycle as described in the relative paragraph. Adjust both mirrors (1) so that you can clearly see the road behind you when seated.



3 • INSTRUCTIONS FOR USE



START-UP OF THE MOTORCYCLE WITH ELECTRICAL STARTER

A cold start is performed when the coolant temperature is below 35°C. Since they use injection, these models are not equipped with a fuel tap.

- 1. Lift the motorcycle and the side stand (1) automatically lifts up.
- 2. Get on the motorcycle from the left side.
- 3. Move the gear shifting pedal (2) into neutral.
- For SMR models, rotate the key (3) of the start switch to "()" ON and Extract the button (4).
- Entirely press or pull the start-up aid lever (5) corresponding to the version of the motorcycle you posses and keep it pulled, or pull the knob (6).
- 6. Pull the clutch lever (7).
- When the throttle is completely closed, press the start button (8) and release it as soon as the engine has started.

A WARNING

After a few seconds from the motor start, move the knob (6) or the lever (5) back to their starting position.

If the motor has a low and irregular idle speed, operate on the adjustment of idle speed (9) as described in the corresponding paragraph "Adjusting idle speed".

The idle speed must always be kept between 2500 and 2800 rpm for 250cc - 300cc engines and between 2200 and 2500 rpm for 450cc engines. This also makes subsequent starts easier.

▲ DANGER

- DO NOT START THE ENGINE IN A CLOSED ROOM AND NEVER LEAVE IT ON IN SUCH ROOMS. EXHAUST GASSES ARE POISONOUS AND THE MAY CAUSE UNCONSCIOUSNESS AND DEATH.
 - IN CASE OF ENGINE OPERATION, ALWAYS MAKE SURE SUFFICIENT VENTILATION IS PRESENT.
- ALWAYS CHECK THAT GEARBOX IS IN NEUTRAL BEFORE STARTING THE MOTORCYCLE. IF A GEAR IS ENGAGED WHEN STARTING THE MOTOR-CYCLE, THE LATTER WILL JUMP FORWARD AND MAY CAUSE DAMAGES TO YOURSELF AND TO THE MOTORCYCLE ITSELF.








SMR



















KICK START OF THE MOTORCYCLE (OPTIONAL)

To start the motorcycle with the kick start, operate as follows:

- 1. Raise the motorcycle, the kickstand (1) will raise automatically.
- **2.** Get on the motorcycle from the left side.
- 3. Position the gearbox lever (2) in neutral.
- **4.** For SMR models, rotate the key (3) of the start switch to "()" ON and check that the button (4) is extracted.
- 5. Entirely press or pull the start-up aid lever (5) corresponding to the version of the motorcycle you posses and keep it pulled, or pull the knob (6).
- 6. Pull the clutch lever (7).
- When your left foot is on the ground and the throttle is completely closed, activate the start pedal (8) using your right foot.

A WARNING

Activate the start pedal 1-2 times using all the available stroke. Do not use the pedal repeatedly and/or for partial strokes; activating the pedal causes the engine to flood.

A WARNING

After a few seconds from the motor start, move the knob (6) or the lever (5) back to their starting position. If the engine has a low and irregular idle speed (9), adjust idle speed as described in the relative paragraph "Engine idle speed adjustment".

The engine idle speed will always have to be kept between 2500 and 2800 rpm for 250cc - 300cc engines and between 2200 and 2500 rpm for 450cc - 530cc engines.

This also makes subsequent starts easier.

A DANGER

- ALWAYS WEAR SOLID MOTORCYCLE BOOTS WHEN KICK STARTING THE ENGINE (OPTIONAL) IN ORDER TO AVOID POSSIBLE INJURIES.
 YOU COULD SLIP FROM THE PEDAL OR THE ENGINE MAY CAUSE A KICKBACK AND CAUSE THE PEDAL TO HIT YOUR FOOT.
- ALWAYS PRESS THE START PEDAL STRONGLY UP TO THE END OF ITS STROKE WITHOUT ACCELERATING. A KICK START WITH A TOO LOW POWER OR WITH THE GAS KNOB OPEN INCREASES THE RISK OF A KICKBACK OF THE ENGINE.
- DO NOT START THE ENGINE IN A CLOSED ROOM AND NEVER LEAVE IT ON IN SUCH ROOMS. EXHAUST GASSES ARE POISONOUS AND THE MAY CAUSE UNCONSCIOUSNESS AND DEATH.
 - IN CASE OF ENGINE OPERATION, ALWAYS MAKE SURE SUFFICIENT VENTILATION IS PRESENT.
- ALWAYS CHECK THAT GEARBOX IS IN NEUTRAL BEFORE STARTING THE MOTORCYCLE. IF A GEAR IS ENGAGED WHEN STARTING THE MOTORCYCLE, THE LATTER WILL JUMP FORWARD AND MAY CAUSE DAMAGES TO YOURSELF AND TO THE MOTORCYCLE ITSELF.






















3 • INSTRUCTIONS FOR USE



COLD START

A cold start is performed when the coolant temperature is below 35°C. Since they use injection, these models are not equipped with a fuel tap.

- 1. Lift the motorcycle and the side stand (1) automatically lifts up.
- 2. Get onto the motorcycle.
- 3. Move the gear shifting pedal (2) into neutral.
- **4.** Entirely press or pull the start-up aid lever (3) corresponding to the version of the motorcycle you posses and keep it pulled, or pull the knob (4).
- 5. With throttle completely closed:
 - SMR: check that the button (5) is extracted; turn the key (6) and then press the ignition button (7) or activate the ignition pedal (8) (OPTIONAL).
 - EN-MX-SMK: press the button (9) or activate the ignition pedal (8) (OPTIONAL).
- **6.** Run the motor by gently accelerating, after approximately 1 minute from the motor start, move the knob (4) back into position. If the motor has a low and irregular idle speed, release the lever (3) or operate on the adjustment knob (10). Idle speed must always be kept between 2500 and 2800 rpm for 250cc 300cc and between 2200 and 2800 rpm 2500 for 450cc. This also eases the following start-ups.



On models without electric start, each time you want to start the engine, use the kick starter 1-2 times, pushing the pedal all the way down. Do not use the pedal repeatedly and/or push it down partially. Using the pedal on these models floods the engine.

A WARNING


Do not rev the engine while it is cold. This could damage the engine. Always warm up the engine before setting off, or by driving at low rpm.

▲ DANGER

- ALWAYS WEAR STRONG MOTORCYCLE BOOTS TO START THE ENGINE
 WITH THE KICK STARTER (OPTIONAL) TO PREVENT INJURIES. YOU
 COULD SLIP OFF THE PEDAL OR THE ENGINE COULD KICK BACK AND
 MAKE YOU HIT YOUR FOOT HARD.
- ALWAYS PUSH THE KICK STARTER ALL THE WAY DOWN VIGOROUSLY WITHOUT ACCELERATING. KICK-STARTING WITH LITTLE FORCE OR WITH THE THROTTLE OPEN INCREASES THE RISK OF ENGINE KICKBACK.
- DO NOT START THE ENGINE IN AN ENCLOSED SPACE AND NEVER LEAVE IT RUNNING IN SUCH SPACES. EXHAUST GASES ARE POISONOUS AND MAY LEAD TO LOSS OF CONSCIOUSNESS AND DEATH. WHEN THE ENGINE IS RUNNING, ALWAYS MAKE SURE THAT THERE IS SUFFICIENT VENTILATION.
- ALWAYS MAKE SURE THAT THE GEAR CONTROL IS IN NEUTRAL BEFORE STARTING THE ENGINE. IF A GEAR IS ENGAGED WHEN STARTING THE ENGINE, THE MOTORCYCLE WILL JUMP FORWARD AND MAY HARM YOU OR DAMAGE THE MOTORCYCLE.





















4-STROKE - (EN)





HOT START

A hot start is performed when the coolant temperature is above 35°C.

- 1. Lift the motorcycle and the side stand (1) automatically lifts up.
- 2. Get onto the motorcycle.
- 3. Move the gear shifting pedal (2) into neutral.
- Entirely press or pull the start-up aid lever (3) corresponding to the version of the motorcycle you posses and keep it pulled, or pull the knob (4).
- 5. With throttle completely closed:
 - SMR: check that the button (5) is extracted; turn the key (6) and then press the ignition button (7) or activate the ignition pedal (8) (OP-TIONAL)
 - EN-MX-SMK: press the button (9) or activate the ignition pedal (8) (OPTIONAL).
- 6. After a few seconds from the motor start, release the lever (3) or, move the knob (4) back into position. If the motor has a low and irregular idle speed, operate on the adjustment knob (10). Idle speed must always be kept between 2500 and 2800 rpm for 250cc 300cc and between 2200 and 2500 rpm for 450cc.

This also eases the following start-ups.



On models without electric start, each time you want to start the engine, use the kick starter 1-2 times, pushing the pedal all the way down. Do not use the pedal repeatedly and/or push it down partially. Using the pedal on these models floods the engine.

A DANGER

- ALWAYS WEAR STRONG MOTORCYCLE BOOTS TO START THE ENGINE
 WITH THE KICK STARTER (OPTIONAL) TO PREVENT INJURIES. YOU
 COULD SLIP OFF THE PEDAL OR THE ENGINE COULD KICK BACK AND
 MAKE YOU HIT YOUR FOOT HARD.
- ALWAYS PUSH THE KICK STARTER ALL THE WAY DOWN VIGOROUSLY WITHOUT ACCELERATING. KICK-STARTING WITH LITTLE FORCE OR WITH THE THROTTLE OPEN INCREASES THE RISK OF ENGINE KICKBACK.
- DO NOT START THE ENGINE IN AN ENCLOSED SPACE AND NEVER LEAVE IT RUNNING IN SUCH SPACES. EXHAUST GASES ARE POISONOUS AND MAY LEAD TO LOSS OF CONSCIOUSNESS AND DEATH. WHEN THE ENGINE IS RUNNING, ALWAYS MAKE SURE THAT THERE IS SUFFICIENT VENTILATION.
- ALWAYS MAKE SURE THAT THE GEAR CONTROL IS IN NEUTRAL BEFORE STARTING THE ENGINE. IF A GEAR IS ENGAGED WHEN STARTING THE ENGINE, THE MOTORCYCLE WILL JUMP FORWARD AND MAY HARM YOU OR DAMAGE THE MOTORCYCLE.





















3 • INSTRUCTIONS FOR USE



KICK START (OPTIONAL) IN THE EVENT OF A FALL


Should the motorcycle fall during sport or competition use, the engine accidentally turns off making it difficult to restart.

Proceed as follows:

- 1. Move the gear shifting pedal (1) into neutral.
- 2. With the throttle fully open, press the engine stop button (2) and use the kick starter(3) about 5 times, pushing down from top to bottom at normal speed.
- 3. With the throttle fully closed, repeat the hot start operation relative to these models.

M WARNING

DO NOT press the button (2) during this last operation.























START WITH FLOODED ENGINE

In case of fall while using the motorcycle for sport or competitive reasons, an accidental shutting off of the engine occurs. In case you find difficulties restarting the motorcycle and you smell petrol, that indicates the engine has flooded.

To start the motorcycle, work as follows:

- 1. Position the gearbox lever (1) in neutral.
- For SMR models, check that the key (2) of the start switch is set to "ON".
- 3. When the throttle (3) is completely open:

SMR

Press the button (4)

MX/SMK/EN

Press and keep pressed the button (4).

Activate the start pedal (5) (OPTIONAL) approximately 5 times from top to bottom at normal speed.

4. When the throttle (3) is completely closed, for **SMR** models, check that the button (4) is in extracted position, then start the motorcycle as described in paragraph "Electric start of the motorcycle"



SETTING OFF

Put on a protective helmet and start the engine, then pull the clutch lever, engage 1st gear and slowly release the clutch lever while accelerating.

▲ DANGER

NEVER RIDE THE MOTORCYCLE WITHOUT WEARING AN APPROVED PROTECTIVE HELMET AND/OR IF YOU ARE NOT IN GOOD PSYCHOLOGICAL AND PHYSICAL HEALTH.

BEFORE SETTING OFF, ALWAYS MAKE SURE THAT THE SIDE STAND IS FULLY RETRACTED. YOU CAN LOSE CONTROL OF THE MOTORCYCLE IF THE STAND DRAGS ON THE GROUND.



ACCELERATING, SHIFTING GEARS, SLOWING DOWN

1st gear, which you are using, is the gear used to set off and to go uphill. When circumstances permit (speed limit, traffic, incline), you can engage higher gears to increase speed. To do so, release the throttle while pulling the clutch lever, engage the next gear, release the clutch and accelerate up to a 1/2 turn of the throttle grip. Then engage the next gear and repeat until you reach the desired speed, always remaining within the limits in force.

Gradually opening the throttle promotes careful driving and limits consumption. Learn how far you need to turn the throttle grip based on the speed at which you want the motorcycle to move.

Release the throttle grip to reduce speed. If necessary, also brake and down shift, pulling the clutch lever and engaging a lower gear. Release the clutch slowly and accelerate or shift gears again. Always move up or down through the gears one at a time!

BRAKING

Release the throttle and, at the same time, gradually brake with the front and rear brakes.

Engage a lower gear if necessary. On dusty, wet or slippery surfaces, use the brakes and down shift as gently as possible without locking the wheels. Locking of the wheels leads to swerving and/or falling.

On long downhill roads, make use of engine braking.

To do so, engage 1st or 2nd gear without excessively increasing the revs. This way, you can brake much less and the brakes will not overheat.

▲ DANGER

- IN RAIN, AFTER WASHING THE MOTORCYCLE, AFTER IMMERSION IN WATER, OR TRAVELLING OVER WET GROUND, BRAKING COULD BE DELAYED BECAUSE OF WET OR DIRTY BRAKE DISCS. THEREFORE, USE THE BRAKES REPEATEDLY AND CAUTIOUSLY, BEING SURE NOT TO OBSTRUCT TRAFFIC, UNTIL THE DISCS ARE DRY AND CLEAN.
- BRAKING CAN BE DELAYED EVEN WHEN TRAVELLING ON DIRTY ROADS OR ROADS COVERED WITH SALT. AGAIN, USE THE BRAKES REPEATEDLY AND CAUTIOUSLY, BEING SURE NOT TO OBSTRUCT TRAFFIC, UNTIL THE DISCS ARE CLEAN.
- DIRTY BRAKE DISCS CAUSE GREATER WEAR OF THE PADS AND DISCS.
- THE DISC, PADS, CALIPERS, AND BRAKE FLUID HEAT UP AFTER USING THE BRAKES. THE HOTTER THESE PARTS, THE LESS THE BRAKING EFFECT IS. IF OVERHEATING OCCURS, THE WHOLE BRAKING SYSTEM MAY FAIL.
- IF, WHILE BRAKING, THE FRONT BRAKE LEVER OR THE REAR BRAKE PEDAL ARE SOFTER THAN USUAL, THERE IS A FAULT IN THE BRAKING SYSTEM. IN THIS CASE, HAVE AN AUTHORIZED TM WORKSHOP CHECK THE MOTORCYCLE.
- TM MODELS CAN BE RESTARTED ANY TIME WITH THE KICK STARTER OR ELECTRIC START. THEREFORE, TURN OFF THE ENGINE WHEN YOU INTEND TO KEEP THE MOTORCYCLE AT A STANDSTILL FOR MORE THAN 2 MINUTES.
- CHECK THE MOTORCYCLE AFTER EVERY FALL AS YOU DO BEFORE EVERY START-UP.
- A TWISTED HANDLEBAR MUST ALWAYS BE REPLACED. NEVER STRAIGHTEN THE HANDLEBAR, AS IT MAY LOSE ITS STRENGTH.

INFORMATION:

Standard TM motorcycles are not equipped with radiator cooling fans and the radiator dimensions are designed for optimum compactness and weight. The cooling system is sufficient for tourist or sport use.

Consult a TM dealer if you want to use optional cooling fans.

A WARNING

- Using the engine at high revs when it is still cold affects the length of engine life. Therefore, before running the engine at full speed, warm
 it up by driving a few kilometers at medium speed. The engine has reached its operating temperature as soon as the radiators become
 hot.
- Never down shift without having first slowed down. The engine revs would go too high and some of its components could be damaged. Also, the rear wheel could lock, causing you to lose control of the vehicle.
- If you feel abnormal vibrations while driving, make sure that the fixing screws on the motorcycle are fully tightened.
- If you hear strange noises while riding your motorcycle, stop immediately, turn off the engine and contact a TM dealer.

3 • INSTRUCTIONS FOR USE



STOPPING AND PARKING

With the throttle fully released, brake the motorcycle until it stops while pulling the clutch lever. Shift into neutral and release the clutch. Keeping the engine at idle speed, press button (1) (EN), button (2) (MX / SMK) or turn the key (3) (SMR) to the "X" position to stop the engine.

We recommend leaving the red engine start prevention button (4) (SMR) pressed in until the next engine start.

Park the motorcycle on solid ground and engage the steering lock, if present.


▲ DANGER

DURING OPERATION, MOTORCYCLES PRODUCE A LOT OF HEAT. THE ENGINE, RADIATORS, EXHAUST SYSTEM, BRAKE DISCS, AS WELL AS SHOCK ABSORBERS, CAN ALL BECOME VERY HOT. NEVER TOUCH THESE PARTS WHEN DRIVING AND AFTER SWITCHING OFF THE ENGINE. PARK THE MOTORCYCLE IN SUCH A WAY AS TO PREVENT PEDESTRIANS FROM TOUCHING IT AND BURNING THEMSELVES.

M WARNING

 Never park with the engine running or park where there is a risk of fire due to dry grass or other easily flammable material.















WASHING

- Regularly clean the motorcycle to keep the surface of plastic parts in good condition.
- Use hot water, a cleaning product available on the market and a sponge.
 Heavy dirt can be removed with a gentle jet of water.
- Plug the exhaust pipe before cleaning to prevent water from going in.
- Remove the air filter as described in the "Maintenance" section.


M WARNING

Do not aim water jets directly at the filter case (1), or water may enter the engine zone.

- Use cleaning products available on the market to wash the engine. Use a suitable brush to clean particularly dirty parts.
- Once you have thoroughly rinsed the motorcycle with a gentle jet of water, dry with compressed air and a cloth.
 Immediately go for a short ride until the engine reaches the operating temperature and, at this point, also use the brakes. The water left in the areas that cannot be reached and on the brakes will evaporate thanks to the heat.
- Once the motorcycle has cooled down, oil or grease all sliding parts and bearings. Apply a specific spray to the chain.
- Apply a specific spray for contacts to all the electrical controls on the handlebar and electrical system connectors to prevent faults in the electrical system.



Never clean the motorcycle with a high pressure cleaner or with a strong water jet! Otherwise, due to the high pressure, water could reach the electrical parts, connectors, flexible cable controls, bearings, etc. and cause faults or lead to early breakage of these parts.



PRECAUTIONS FOR WINTER USE

If the motorcycle is used in winter, you must consider the salt on the roads and take appropriate measures against the corrosive salt.

- Thoroughly wash the motorcycle after every use and let it dry.
- Apply an anti-corrosion product to the engine, exhaust system, frame, swing arm and all other shiny, galvanized or satin finished metal components (except brake discs).

A DANGER

DO NOT ALLOW THE ANTI-CORROSION PRODUCT TO COME INTO CONTACT WITH THE BRAKE DISCS. THIS WOULD REDUCE THE BRAKING EFFECT CONSIDERABLY.

A WARNING

After traveling on roads where salt has been spread, thoroughly wash the motorcycle with cold water and let it dry completely.

3 • INSTRUCTIONS FOR USE



STORAGE

Take the following measures if the motorcycle is to be left unused for a long period:

- Thoroughly clean the motorcycle (see "WASHING").
- Change the engine oil and the cartridge oil filter. Old oil contains harmful impurities (see the "MAINTENANCE" section).
- Check the coolant level.
- Remove the spark plug and pour approx. 5 cc of engine oil into the cylinder through the spark plug hole. Activate the kick starter 10 times to allow the engine oil to be distributed on the cylinder wall. Then fit the spark plug again.
- Compress the piston to make the valves close.
- Empty the fuel tank and collect the fuel in a suitable container.
- Disconnect the cables and remove the battery. Plan a maintenance schedule if required.
- Adjust the tire pressure.
- Grease the bearings, control lever and footrest supports and the chain.
- The storage area should be dry and not subject to drastic temperature changes.
- Cover the motorcycle, preferably with a breathable sheet or cover. Do not use airtight materials, as moisture would be trapped and could cause corrosion.
- Place the motorcycle on a stand, so that its wheels are raised off the ground.

A WARNING

Before storing the motorcycle for the winter, check the operation and wear of all components. If maintenance operations, repairs or modifications are required, it is a good idea to have them carried out during the winter (workshops are less busy). This means that you avoid long waits in the workshop at the start of the spring season.

M WARNING

It is highly inadvisable to start the engine for brief periods of time when the motorcycle has been put into storage. The engine would not heat up sufficiently, and so the steam created during combustion would condense, oxidizing the valves and the exhaust system.

START-UP AFTER WINTER

- Fit the charged battery.
- Fill the tank with new fuel.
- Check the motorcycle as you do before any start-up. Go for a short test ride.

4-STROKE - EN



4. MAINTENANCE









MX 250 - 300 ES FI MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 15 hours	Every 30 hours (after every racing)	Every 45 hours	Every 95 hours (45 hours of competition)	Every 135 hours (75 hours of competition)	Every year
Check steering bearings and play adjustment	•	•	•				
Clean and grease steering bearings and relative sealing elements							•
Bleed telescopic fork		•	•				
Clean dust seal			•				
Check seal and operation of fork and shock absorber			•				
Full fork maintenance				•		•	
Full shock absorber maintenance				•		•	
Check tightness of screws and linkage smooth running for rear suspension		•	•				
Check frame and swing arm		•	•				
Check swing arm bearings			•				
Lubricate movable parts (side stand, levers, etc.) and check their movement		•	•				
Check tightness of chassis screws (fork plates, fork feet, wheel pin nuts and screws, swing arm pin, shock absorber)	•	•	•				
Check wear on chain, junction mesh, pinion, sprocket and guides, chain tension		•	•				
Lubricate chain		•	•				
Check fluid level in hydraulic clutch control tank		•	•				
Change hydraulic clutch fluid							•
Check brake fluid level, pad thickness, front and rear brake discs		•	•				
Change front and rear brake fluid							•
Check condition and seal of brake pipes		•	•				
Check operation, adjustment, smoothness and play of front brake lever and rear brake pedal		•	•				
Check tightness of braking system screws		•	•				
Check wheel hubs, spoke tension and rim centering	•	•	•				
Check wheel bearing play		•	•				
Check tire condition and pressure	•	•	•				
Check battery and charge it if necessary		•	•				
Treat battery connections with grease for contacts		•	•				
Treat electrical contacts and switches with spray for contacts		•	•				
Check headlight orientation	•	•	•				
Check electrical system operation (low beam, high beam, stop light, turn signals, control indicators, horn, safety button/switch)		•	•				
Check cooling system seal and coolant level	•	•	•				
Check condition and arrangement of rubber pipes without bends	•	•	•				
Check condition and arrangement of bleeder hoses without bends	•	•	•				
Check electric fan operation (if installed)	•	•	•				
Replace silencer soundproofing material			•				
Check exhaust system seal and fastening	•	•	•				
Clean air filter and filter housing		•	•				
Check condition and seal of throttle body coupler and filter housing		•	•				
Check fuel pressure		•	•				
Check throttle cable play and idle speed adjustment	•	•	•				
Check condition, smoothness and arrangement without bends, adjustment and lubrication of control cables		•	•				
Change engine oil and cartridge oil filter	•	•	•				
4•57						(EN) - 4	4-STROKE



MX 250 - 300 ES FI MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 15 hours	Every 30 hours (after every racing)	Every 45 hours	Every 95 hours (45 hours of competition)	Every 135 hours (75 hours of competition)	Every year
Clean oil mesh filter						•	
Clean exhaust screw magnet		•	•				
Check tightness of engine fixing screws	•	•	•				
Replace spark plug and check cap						•	
Check valve clearance			•				
Check timing belt				•			
Replace timing belt					•		
Check cylinder and piston wear				•			
Fully change piston					•		
Check head				•			
Check camshafts and rocker arms				•			
Replace valves, springs, half cones and plates						•	
Fully change conrod						•	
Check clutch discs				•			
Check clutch springs				•			
Check transmission and gearbox						•	
Check oil pumps and lubricating circuit					•		
Fully change engine bearings						•	
Fully change engine oil seal						•	
Replacing the engine oil, oil filter, cartridges	•	•	•	•			

A WARNING

Change affected components if a defect is found or wear limits exceeded.

The above operations must be performed by an authorized TM workshop or by specialized personnel.

The hour meter is built into the dash.



MX 250 - 300 ES FI / SMK 250 MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 10 hours (after every racing)	Every 20 hours (after every racing)	Every 30 hours	Every 40 hours	Every 50 hours	Every 75 hours	Every year
Check steering bearings and play adjustment	•	•	•	•	•			
Clean and grease steering bearings and relative sealing elements								•
Bleed telescopic fork		•	•	•	•			
Clean dust seal		•	•	•	•			
Check seal and operation of fork and shock absorber		•	•	•	•			
Full fork maintenance				•				
Full shock absorber maintenance				•				
Check tightness of screws and linkage smooth running for rear suspension		•		•				
Check frame and swing arm		•	•	•	•			
Check swing arm bearings			•		•			
Lubricate movable parts (side stand, levers, etc.) and check their movement		•	•	•	•			
Check tightness of chassis screws (fork plates, fork feet, wheel pin nuts and screws, swing arm pin, shock absorber)	•	•	•	•	•			
Check wear on chain, junction mesh, pinion, sprocket and guides, chain tension		•	•	•	•			
Lubricate chain		•		•				
Check fluid level in hydraulic clutch control tank		•	•	•	•			
Change hydraulic clutch fluid								•
Check brake fluid level, pad thickness, front and rear brake discs		•	•	•	•			
Change front and rear brake fluid								•
Check condition and seal of brake pipes		•	•	•	•			
Check operation, adjustment, smoothness and play of front brake lever and rear brake pedal		•	•	•	•			
Check tightness of braking system screws		•		•				
Check wheel hubs, spoke tension and rim centering	•	•	•	•	•			
Check wheel bearing play		•	•	•	•			
Check tire condition and pressure	•	•	•	•	•			
Check battery and charge it if necessary (only models with E.S.)		•	•	•	•			
Treat battery connections with grease for contacts (only models with E.S.)		•	•	•	•			
Treat electrical contacts and switches with spray for contacts		•	•	•	•			
Check cooling system seal and coolant level	•	•	•	•	•			
Check condition and arrangement of rubber pipes without bends	•	•	•	•	•			
Check condition and arrangement of bleeder hoses without bends	•	•		•				
Replace silencer soundproofing material		•	•	•	•			
Check exhaust system seal and fastening	•	•	•	•	•			
Clean air filter and filter housing		•	•	•	•			



MX 250 - 300 ES FI / SMK 250 MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 10 hours (after every racing)	Every 20 hours (after every racing)	Every 30 hours	Every 40 hours	Every 50 hours	Every 75 hours	Every year
Check condition and seal of throttle body coupler and filter housing	•	•	•	•	•			
Check fuel pressure		•	•	•	•			
Check throttle cable play and idle speed adjustment	•	•	•	•	•			
Check condition, smoothness and arrangement without bends, adjustment and lubrication of control cables		•	•	•	•			
Change engine oil and cartridge oil filter	•	•	•	•	•			
Clean oil mesh filter							•	
Clean exhaust screw magnet	•	•	•	•	•			
Check tightness of engine fixing screws	•	•	•	•	•			
Replace spark plug and check cap					•			
Check valve clearance				•	•			
Check timing belt					•		•	
Replace timing belt					•			
Check cylinder and piston wear and chain tensioner				•		•		
Fully change piston					•			
Check head						•	•	
Check camshafts and rocker arms					•		•	
Replace valves, springs, half cones and plates							•	
Fully change conrod							•	
Check clutch discs			•		•			
Check clutch springs			•		•			
Check transmission and gearbox							•	
Check oil pumps and lubricating circuit							•	
Fully change engine bearings							•	
Fully change engine oil seal							•	

A WARNING

Change affected components if a defect is found or wear limits exceeded.

We recommend that you fit an hour meter.

The above operations must be performed by an authorized TM workshop or by specialized personnel.



EN - SMR 450 ES FI MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 15 hours	Every 30 hours (after every racing)	Every 45 hours	Every 95 hours	Every 135 hours (75 hours of competition)	Every year
Check steering bearings and play adjustment	•	•	•				
Clean and grease steering bearings and relative sealing elements							•
Bleed telescopic fork		•	•				
Clean dust seal			•				
Check seal and operation of fork and shock absorber			•				
Full fork maintenance				•		•	
Full shock absorber maintenance				•		•	
Check tightness of screws and linkage smooth running for rear suspension		•	•				
Check frame and swing arm		•	•				
Check swing arm bearings			•				
Lubricate movable parts (levers, etc.) and check their movement		•	•				
Check tightness of chassis screws (fork plates, fork feet, wheel pin nuts and screws, swing arm pin, shock absorber)	•	•	•				
Check wear on chain, junction mesh, pinion, sprocket and guides, chain tension		•	•				
Lubricate chain		•	•				
Check fluid level in hydraulic clutch control tank		•	•				
Change hydraulic clutch fluid							•
Check brake fluid level, pad thickness, front and rear brake discs		•	•				
Change front and rear brake fluid							•
Check condition and seal of brake pipes		•	•				
Check operation, adjustment, smoothness and play of front brake lever and rear brake pedal		•	•				
Check tightness of braking system screws		•	•				
Check wheel hubs, spoke tension and rim centering	•	•	•				
Check wheel bearing play		•	•				
Check tire condition and pressure	•	•	•				
Check and charge battery		•	•				
Treat battery connections with grease for contacts		•	•				
Treat electrical contacts and switches with spray for contacts		•	•				
Check headlight orientation	•	•	•				
Check electrical system operation (low beam, high beam, stop light, turn signals, control indicators, horn, safety button / switch)		•	•				
Check cooling system seal and coolant level	•	•	•				
Check condition and arrangement of rubber pipes without bends	•	•	•				
Check condition and arrangement of bleeder hoses without bends	•	•	•				
Check solenoid valve operation (if installed)	•	•	•				
Replace silencer soundproofing material			•				
Check exhaust system seal and fastening	•	•	•				
Clean air filter and filter housing		•	•				
Check condition and seal of throttle body coupler and filter housing		•	•				
Check fuel pressure		•	•				
Check throttle cable play and idle speed adjustment	•	•	•				
Check condition, smoothness and arrangement without bends, adjustment and lubrication of control cables		•	•				

- 4•61 **-**



EN - SMR 450 ES FI MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 15 hours	Every 30 hours (after every racing)	Every 45 hours	Every 95 hours	Every 135 hours (75 hours of competition)	Every year
Change engine oil and cartridge oil filter	•	•	•				
Clean oil mesh filter					•		
Clean exhaust screw magnet		•	•				
Check tightness of engine fixing screws	•	•	•				
Replace spark plug and check cap						•	
Check valve clearance			•				
Check timing belt			•				
Replace timing belt				•			
Check cylinder and piston wear				•		•	
Fully change piston				•		•	
Check head				•		•	
Check camshafts and cups					•		
Replace valves, springs, half cones and plates					•		
Fully change conrod				•		•	
Check clutch discs				•		•	
Check clutch springs				•		•	
Check transmission and gearbox						•	
Check oil pumps and lubricating circuit						•	
Fully change engine bearings					•		
Fully change engine oil seal					•		

M WARNING

Change affected components if a defect is found or wear limits exceeded.

The above operations must be performed by an authorized TM workshop or by specialized personnel.

The hour meter is built into the dash.



MX - SMK 450 ES FI MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 10 hours (after every racing)	Every 20 hours	Every 30 hours	Every 40 hours	Every 50 hours	Every 75 hours	Every year
Check steering bearings and play adjustment	•	ш •	•	•	ш •		w	
Clean and grease steering bearings and relative sealing elements								•
Bleed telescopic fork		•	•	•	•			
Clean dust seal		•	•	•	•			
Check seal and operation of fork and shock absorber		•	•	•	•			
Full fork maintenance				•				
Full shock absorber maintenance				•				
Check tightness of screws and linkage smooth running for rear suspension		•		•				
Check frame and swing arm		•	•	•	•			
Check swing arm bearings			•		•			
Lubricate movable parts (levers, etc.) and check their movement		•	•	•	•			
Check tightness of chassis screws (fork plate, fork feet, wheel pin nuts and screws, swing arm pin, shock absorber)	•	•	•	•	•			
Check wear on chain, junction mesh, pinion, sprocket and guides, chain tension		•	•	•	•			
Lubricate chain								
Check fluid level in hydraulic clutch control tank		•	•	•	•			
Change hydraulic clutch fluid		•		•				•
Check brake fluid level, pad thickness, front and rear brake discs		•	•	•	•			
Change brake fluid								•
Check condition and seal of brake pipes		•	•	•	•			
Check operation, adjustment, smoothness and play of front brake lever and rear brake pedal		•	•	•	•			
Check tightness of braking system screws		•		•				
Check wheel hubs, spoke tension and rim centering	•	•	•	•	•			
Check wheel bearing play		•	•	•	•			
Check tire condition and pressure	•	•	•	•	•			
Check battery and charge it if necessary (only models with E.S.)		•	•	•	•			
Treat battery connections with grease for contacts (only models with E.S.)		•	•	•	•			
Treat electrical contacts and switches with spray for contacts		•	•	•	•			
Check cooling system seal and coolant level	•	•	•	•	•			
Check condition and arrangement of rubber pipes without bends	•	•	•	•	•			
Check condition and arrangement of bleeder hoses without bends	•	•						
Replace silencer soundproofing material			•		•			
Check exhaust systems seal and fastening	•	•	•	•	•			
Clean air filter and filter housing		•	•	•	•			
Check condition and seal of throttle body coupler and filter housing	•	•	•	•	•			



MX - SMK 450 ES FI MAINTENANCE TABLE

A CLEAN MOTORCYCLE CAN BE INSPECTED FASTER AND AT A LOWER COST

	After 1 hour	Every 10 hours (after every racing)	Every 20 hours	Every 30 hours	Every 40 hours	Every 50 hours	Every 75 hours	Every year
Check fuel pressure		•	•	•	•			
Check throttle cable play and idle speed adjustment	•	•	•	•	•			
Check manual decompression lever (530 Fi)	•	•	•	•	•			
Check condition, smoothness and arrangement without bends, adjustment and lubrication of control cables		•	•	•	•			
Change engine oil and cartridge oil filter	•	•	•	•	•			
Clean oil mesh filter							•	
Clean exhaust screw magnet	•	•	•	•	•		•	
Check tightness of engine fixing screws	•	•	•	•	•			
Replace spark plug and check cap							•	
Check valve clearance			•	•				
Check timing belt			•					
Replace timing belt				•			•	
Check cylinder and piston wear				•		•		
Fully change piston				•	•			
Check head				•				
Check camshafts and cups						•	•	
Replace valves, springs, half cones and plates						•		
Fully change conrod						•		
Check clutch discs			•		•			
Check clutch springs			•		•			
Check transmission and gearbox							•	
Check oil pumps and lubricating circuit						•		
Fully change engine bearings						•		
Fully change engine oil seal							•	

M WARNING

Change affected components if a defect is found or wear limits exceeded.

We recommend that you fit an hour meter.

The above operations must be performed by an authorized TM workshop or by specialized personnel.





THIS SYMBOL ALONGSIDE THE TITLE MEANS THAT THE OPERATION MUST BE PERFORMED AT AN AUTHORIZED TM WORKSHOP.

FORK COMPRESSION ADJUSTMENT

The compression hydraulic braking system determines the fork compression stroke. The degree of compression hydraulic braking can be adjusted to suit the rider and/or the installed spring rate.

KAYABA USD FORK

The adjusting screw (1) is in the upper part of the fork cap. Use a screwdriver. Turn it clockwise to increase braking, or anti-clockwise to reduce it. There are a total of 19 clicks available.

M WARNING

Do not touch the bleeder screw (2).


A WARNING

Before starting, tighten the adjuster from the standard position to "fully closed" while counting the clicks. Write down the number of clicks counted so that you can restore the standard adjustment if necessary. The clicks are normally indicated from the "fully closed" position.

Both tubes must be adjusted in the same way.

	ADJUSTING THE STROKE
EN	14 clicks from fully closed

	STANDARD ADJUSTMENT
MX	12 clicks from fully closed
EN	16 clicks from fully closed
SMR	17 clicks from fully closed
SMX	12 clicks from fully closed





FORK REBOUND ADJUSTMENT

The rebound hydraulic braking system determines the fork rebound stroke. The degree of rebound hydraulic braking can be adjusted to suit the rider and/or the installed spring rate.

KAYABA USD FORK

The adjusting screw (1) is in the lower part of the fork foot. Use a screwdriver. Turn it clockwise to increase braking, or anti-clockwise to reduce it. There are a total of 21 clicks available.


A WARNING

Do not touch the hexagon nut (2) as it is not needed to alter rebound braking.

A WARNING

Before starting, tighten the adjuster from the standard position to "fully closed" while counting the clicks. Write down the number of clicks counted so that you can restore the standard adjustment if necessary. The clicks are normally indicated from the "fully closed" position.

Both tubes must be adjusted in the same way.



	ADJUSTING THE STROKE
EN	14 clicks from fully closed

	STANDARD ADJUSTMENT
MX	12 clicks from fully closed
EN	16 clicks from fully closed
SMR	15 clicks from fully closed
SMX	12 clicks from fully closed

4-STROKE - EN



VARYING PRE-LOAD AND REPLACING FORK SPRINGS

To vary the spring pre-load on these forks, you must partly disassemble them (see the specific manual of the fork fitted on the motorcycle). You should absolutely not vary the spring pre-load on forks fitted by TM

You should absolutely not vary the spring pre-load on forks fitted by TM Racing.

If necessary, replace the springs with others that have a different rate.

M WARNING

For further, more detailed information about the forks, see the instructions supplied by the fork manufacturer.

BLEEDING THE TELESCOPIC FORK

After every 5 hours of competition use, use the bleeder screws or valves to release any overpressure from inside the fork.

KAYABA USD FORK

The Kayaba fork has a screw (1).

- Before using the screw, lift the motorcycle onto a central stand so that the front wheel is not touching the ground.
- Unscrew the screw (1) completely without removing it and bleed the
- Tighten the screw (1) again.
- If the motorcycle is mainly used on the road, this operation only needs to be performed during regular maintenance.

M WARNING

Excessive pressure inside the fork may cause oil to leak from the fork. If your fork leaks oil, try bleeding the air before replacing the sealing elements.







CLEANING TELESCOPIC FORK DUST SEAL

NOTE: You must contact a TM dealer to carry out this operation.


The dust seal (1) must prevent dust and dirt from entering the fork oil seal. However, dirt may get behind the dust seal over time. If the dirt is not removed, the oil seal ring, located behind it, may lose its seal.


Use a screwdriver to very carefully separate the dust seal (1) and the scrapper (2) from the outer tube (3) and push it down.

- Carefully clean the dust seal (1), the scrapper (2), the outer tube (3) and the inner tube (4) and liberally oil with silicone spray or with engine oil.
- Then re-fit the dust seal and the scrapper by manually pushing it into the seat in the outer tube.



Perform this operation on both of the fork dust seals.





SHOCK ABSORBER COMPRESSION ADJUSTMENT

TM SHOCK ABSORBER

You can access the adjusting screw on the right-hand side of the motorcycle.

Low speeds


The adjusting screw (1) is on top of the shock absorber gas tank. Use a 5 mm Allen key. Turn it clockwise to increase braking, or anti-clockwise to reduce it. There are a total of 24 clicks available.

ADJUSTING THE STROKE		
250-300 EN	17 clicks from fully closed	
450 EN	16 clicks from fully closed	

	STANDARD ADJUSTMENT
250-300 MX	17 clicks from fully closed
450-530 MX	17 clicks from fully closed
250-300 EN	14 clicks from fully closed
450 EN	14 clicks from fully closed
250-300 SMK	15 clicks from fully closed
450 SMK	15 clicks from fully closed
450 SMR	15 clicks from fully closed

High speeds

The hexagon ring adjuster (2) is concentric to the low speed adjusting screw. Use a 14 mm hex wrench. Turn it clockwise to increase braking, or anti-clockwise to reduce it. There are a total of 28 clicks available.



4-STROKE - (EN) 4-68



ADJUSTING THE STROKE		
250-300 EN	12 clicks from fully closed	
450 EN	12 clicks from fully closed	

	STANDARD ADJUSTMENT
250-300 MX	10 clicks from fully closed
450-530 MX	10 clicks from fully closed
250-300 EN	10 clicks from fully closed
450 EN	10 clicks from fully closed
250-300 SMK	8 clicks from fully closed
450 SMK	10 clicks from fully closed
450 SMR	12 clicks from fully closed

WARNING

Before starting, tighten the adjuster from the standard position to "fully closed" while counting the clicks. Write down the number of clicks counted so that you can restore the standard adjustment if necessary.

The clicks are normally indicated from the "fully closed" position.

SHOCK ABSORBER REBOUND ADJUSTMENT

TM SHOCK ABSORBER

You can access the adjusting screw on the left-hand side of the motorcycle.

The adjusting screw (1) is on the fork coupling connecting the shock absorber to the linkage. Use a screwdriver. Turn it clockwise to increase braking, or anti-clockwise to reduce it. There are a total of 34 clicks available.

A WARNING

Before starting, tighten the adjuster from the standard position to "fully closed" while counting the clicks. Write down the number of clicks counted so that you can restore the standard adjustment if necessary.

The clicks are normally indicated from the "fully closed" position.

ADJUSTING THE STROKE		
250-300 EN	22 clicks from fully closed	
450 EN	22 clicks from fully closed	

	STANDARD ADJUSTMENT
250-300 MX	22 clicks from fully closed
450-530 MX	20 clicks from fully closed
250-300 EN	24 clicks from fully closed
450 EN	24 clicks from fully closed
250-300 SMK	22 clicks from fully closed
450 SMK	22 clicks from fully closed
450 SMR	28 clicks from fully closed





VARYING PRE-LOAD AND REPLACING SHOCK ABSORBER SPRING

The spring pre-load can be varied by turning the adjusting ring. Each 1 turn of the adjusting ring varies the pre-load by 1.5 mm.

To make this operation easy, disassemble and carefully clean the shock absorber.


If pre-load variation is insufficient, you must replace the spring with one that has a different spring rate.

A WARNING

Before starting, write down the basic adjustment. For example, how many turns of thread are visible above the adjusting ring.

- Loosen the locknut (1) and rotate the la nut (2).
- Rotate it anticlockwise (from above) to decrease pre-load, rotate it clockwise (from above) to increase pre-load.
- Tighten the locknut (1) after adjustment.







BASIC SUSPENSION CALIBRATION DEPENDING ON THE WEIGHT OF THE RIDER

For optimum motorcycle driving and to prevent the fork, shock absorber, swing arm and frame from being damaged, the basic calibration of the suspensions must be adjusted according to your weight.

The basic calibration of the suspensions (both the fork and shock absorber) involves mounting a certain type of spring and a set of adjustments of the compression and rebound braking.

TM motorcycles come calibrated for a rider weight (with full protective gear) of 70 - 80 kg. Adjust the calibration of the suspensions if your weight does not fall within this range.

The main element to check is the spring, both of the fork and the shock absorber. To check for correct spring rate, first measure the motorcycle rider sag.

Then adjust the compression and rebound braking.

For technical clarification regarding operation and calibration of TM motorcycle suspensions, contact your local TM dealer.

ADAPTING FORK BASIC CALIBRATION

Precise fork rider sag cannot be established for several reasons.

Minor variations in your body weight can be compensated for by adjusting the compression braking.

But if your fork is often bottoming or topping out, you must fit stiffer springs to avoid damaging the fork and frame.

Then re-adjust the compression and rebound braking.

ADAPTING SHOCK ABSORBER BASIC CALIBRATION

To establish whether or not the shock absorber spring is suitable for your weight, check rider sag.

But first the shock absorber static sag must be adjusted.

Both static sag and rider sag can be checked by taking a simple set of measurements on the motorcycle.



CHECKING SHOCK ABSORBER STATIC SAG

Correct shock absorber static sag corresponds to a static lowering of the motorcycle by 40 mm.

Variations exceeding 2 mm may affect motorcycle handling.

Procedure:

- Place the motorcycle on a stand, so that the rear wheel is not touching the ground.
- Measure the distance between the rear wheel pin and a fixed point (e.g.: a reference on a side) making sure that the straight line connecting the wheel pin to the fixed point is as perpendicular to the ground as possible and write down the value as measurement A.
- Place the motorcycle on the ground again.
- Ask someone to keep the motorcycle in an upright position.
- Measure the distance between the rear wheel pin and the fixed point again and write the value down as measurement B.
- The static sag is the difference between measurements A and B.

Example:

If the static sag is less than that, reduce the shock absorber spring pre-load. If the static sag is greater than that, increase the spring pre-load.

See the "Varying pre-load and replacing shock absorber spring" section.

CHECKING SHOCK ABSORBER RIDER SAG

Correct shock absorber rider sag should correspond to a lowering of the motorcycle of 95 - 105 mm.

Procedure:

- Ask someone to hold the motorcycle. Sit on the seat wearing full
 protective gear in the normal position (feet on the footrests) and bounce
 up and down a few times to allow the rear suspension set-up to settle.
- With the motorcycle loaded in this way, measure the distance between the same measuring points and write the value down as measurement C.
- The rider sag is the difference between measurements A and C.


Example:

- Rider sag 90 mm

If rider sag is less than 90 mm, the spring is too "hard" (spring rate too high). If the rider sag is greater than 105 mm, the spring is too "soft" (spring rate too low).

The spring rate is indicated on the spring wire. After fitting a different spring, set the static sag to 35 mm (± 2 mm) again.

In our experience, after replacing the spring with one that has a different spring rate, the degree of compression damping may remain unchanged. With a "softer" spring the degree of rebound damping can be reduced by several clicks, and with a "harder" spring it can be increased by several clicks.





CHECKING STEERING BEARINGS AND PLAY ADJUSTMENT

- Regularly check steering bearing play.
- Position the motorcycle so that the front wheel is raised, turn the handlebar in both directions and move the fork back and forth. If the steering is hard to turn, the bearings are too tight and you need to loosen the ring nut (3). If the steering shakes, the bearings have play and ring-nut (3) must be tightened.
- To adjust, loosen the four M8 screws (1) and nut (2) of the fork head and tighten or loosen ring-nut (3) as necessary.
 Do not tighten ring nut (3) beyond the play elimination point to avoid damaging the bearings. Tighten the fork head nut and then the four M8 screws to 17 Nm.
- Make sure steering is smooth, without sticking or play.


▲ DANGER


IF THE STEERING BEARINGS ARE TOO TIGHT OR HAVE PLAY, MOTORCYCLE HANDLING ON THE ROAD WILL BE IRREGULAR AND YOU COULD LOSE CONTROL OF THE MOTORCYCLE.

M WARNING

Long journeys without the correct steering bearing adjustment could ruin the bearings and their seats in the frame.

The steering bearings must be re-greased at least once a year.









REAR SUSPENSION LINKAGE

The rear suspension of all TM motorcycles is equipped with a conrod and rocker mechanism that gradually modifies the leverage ratio between the wheel and shock absorber.

This mechanism works on the bearings, which must be cleaned and greased at the scheduled intervals to keep suspension operation efficient.

When washing the motorcycle with high pressure cleaners do not direct the jet at the suspension linkage.



CHECKING CHAIN TENSION


- To check chain tension, put the motorcycle up on the center stand.
- Push the chain upwards at the end of the chain guide.

The upper branch of the chain must be taut.

The distance between the swing arm and the lower branch of the chain (A) must be approx. 10 - 15 mm. Adjust the tension if necessary.

▲ DANGER

- IF THE CHAIN IS TOO TIGHT, THE FINAL TRANSMISSION COMPONENTS (CHAIN, PINION AND SPROCKET, GEARBOX AND REAR WHEEL BEARINGS) ARE SUBJECT TO MORE STRESS. IN ADDITION TO PREMATURE WEAR, IN EXTREME CASES, THE CHAIN OR THE GEARBOX SECONDARY SHAFT MAY BREAK.
- INSTEAD, IF THE CHAIN TENSION IS INSUFFICIENT IT CAN JUMP OFF THE PINION AND LOCK THE REAR WHEEL OR DAMAGE THE FINGINE
- IN BOTH CASES YOU CAN EASILY LOSE CONTROL OF THE MOTORCYCLE.






TENSIONING THE CHAIN

- Loosen the wheel pin nut (1), loosen the lock nuts (2) on both sides and turn the adjusting screws (3) on both sides, by the same extent.
- To increase chain tension, unscrew the adjusting screws.
- To reduce chain tension, tighten the adjusting screws.
 Do this until you achieve the correct chain tension.
- To align the rear wheel correctly, the marks (4) on the right and left chain tensioner must be in the same position relative to the reference marks (5).
- Tighten the lock nuts (2) of the adjusting screws (3).
- Before locking the wheel pin nut, ensure that the chain tensioners (6) are resting on the heads of the adjusting screws and that the rear wheel is aligned with the front wheel.
- Tighten the wheel pin nut (1) to 80 Nm.



If for assembly operations you do not have a torque wrench, get the tightening torque corrected as soon as possible at a specialized TM workshop.

An incorrectly tightened wheel pin may make the motorcycle unstable.



CHAIN MAINTENANCE

The life span of the chain depends above all on maintenance.

Chains without an O-ring must be regularly cleaned in oil and then immersed in hot oil or treated with chain spray.

Maintenance of chains with O-ring is minimal.

The best way to clean it is with plenty of water.

Never use brushes or solvents to clean the chain.

When the chain is dry, use a specific spray for chains with O-rings.

A DANGER

IT IS ESSENTIAL TO PREVENT THE LUBRICANT FROM REACHING THE REAR TIRE AND THE BRAKE DISC. OTHERWISE THE REAR WHEEL'S GRIP ON THE GROUND AND THE REAR BRAKE ACTION COULD BE SIGNIFICANTLY REDUCED AND YOU COULD EASILY LOSE CONTROL OF THE MOTORCYCLE.

M WARNING

When assembling the chain joint (1), the closed part must always be in the direction of travel.

Always check for wear on the pinions, sprocket and guides. Replace these parts if necessary.



4 • MAINTENANCE




CHAIN WEAR

To check the level of wear on the chain, carefully follow these instructions:

- Shift into neutral, pull the upper branch of the chain upwards with a force of 10 - 15 kg.
- Now measure the distance of 18 links on the lower branch of the chain. If the distance is more than 272 mm, replace the chain.

Chains do not always wear evenly, therefore, you must repeat the measurement at various points of the chain.


When a new chain is fitted, also replace the pinion and sprocket. A new chain wears faster on old and worn pinions and sprocket.



⚠ WARNING

When replacing the chain, pinion and sprocket, we recommend fitting new self-locking nuts for the sprocket and using criss-cross tightening.

The nut tightening torque is 35 Nm.





HYDRAULIC CLUTCH PUMP

ADJUSTING THE LEVER POSITION


The position of the clutch lever (1) relative to the grip can be altered using the adjusting knob (2).

 Turn the knob (2) by clicks, clockwise to move the lever away or anticlockwise to move the lever closer.

M WARNING

When the operation is complete, check that there is some play in the clutch lever before the clutch is engaged.

The play must be around 3 mm.





CHECKING AND TOPPING UP THE HYDRAULIC FLUID LEVEL

The fluid reservoir is part of the clutch pump located on the handlebar.


- Remove the screws (3), cover (4), and membrane (5).
- With the reservoir in a horizontal position the fluid level must be 5 mm below the edge.
- Top up if necessary. Use DOT4 brake hydraulic fluid.
- Re-fit the membrane, cover and screws and tighten them. Use water to wash away any hydraulic fluid that overflowed or was spilled.

▲ DANGER

- IF THE LEVEL OF THE HYDRAULIC FLUID DROPS BELOW THE PRESET LEVEL, THERE COULD BE LEAKS IN THE SYSTEM OR EARLY SIGNS OF A MECHANICAL PROBLEM.
- STORE HYDRAULIC FLUID OUT OF THE REACH OF CHILDREN.
- HYDRAULIC FLUID MAY IRRITATE SKIN. AVOID CONTACT WITH SKIN AND EYES. IF HYDRAULIC FLUID SPLASHES IN YOUR EYES, RINSE THOROUGHLY WITH WATER AND SEEK MEDICAL ADVICE.

M WARNING

- Only use DOT4 brake hydraulic fluid for the clutch hydraulic control.
 Never use DOT5 or other fluids.
- Prevent contact between brake hydraulic fluid and painted parts. Brake fluid corrodes paint.
- Only use clean brake fluid from a hermetically sealed container.








BLEEDING THE HYDRAULIC CLUTCH

- Remove the cover of the clutch pump on the handlebar to bleed the air.
- Connect the suction device to the bleeder screw (1) of the clutch cylinder on the engine and activate it while loosening bleeder screw (1).
 Continue until only fluid comes out of the bleeder screw (1).
- Tighten the bleeder screw (1).
- Disconnect the suction device.
 During this operation make sure that the clutch pump reservoir level is always sufficient to prevent the pump from drawing air. Top up with DOT4 brake hydraulic fluid as required.



- Use DOT4 brake hydraulic fluid for the clutch hydraulic control. Never use DOT5 or other fluids.
- Prevent contact between brake fluid and painted parts. Brake fluid corrodes paint.
- Only use clean brake fluid from a hermetically sealed container.







BASIC INDICATIONS FOR TM DISC BRAKES

CALIPERS

EN and MX models have floating front and rear calipers, i.e.: they are not joined to their support. Side compensation always allows the pads to rest on the discs in the optimum way. The brake caliper supporting screws must be secured with Loctite 243 and tightened to 25 Nm.

Mounting of the front calipers of versions SMR/SMK is of the fixed type.

PADS

The minimum thickness of the friction material must never drop below 1 mm. In the event of replacement, we recommend that you always use the specific TM original spare part for your motorcycle.

4-STROKE - EN

4•78




BRAKE DISCS

- Wear reduces the thickness of the brake disc in the pad contact surface
 (1) zone.
- At their thinnest point (A), brake discs must have a thickness greater than the minimum thickness measurement "A" stamped on the disc.


A DANGER

- BRAKE DISCS WHOSE THICKNESS IS LESS THAN THAT STAMPED ON THE DISC ARE A SAFETY RISK. WHEN THE WEAR LIMIT IS REACHED, REPLACE THE BRAKE DISCS IMMEDIATELY.
- HAVING THE BRAKING SYSTEM REPAIRED BY AN AUTHORIZED TM WORKSHOP IS MANDATORY.



BRAKE FLUID RESERVOIRS

The brake fluid reservoirs for the front and rear brake are sized so that topping up is not necessary even if the brake pads are worn. In fact, as the pads wear, the fluid in the pipes takes up the space left by the pistons which have shifted to allow the pad to always rest on the disc. If the brake fluid level drops below the minimum value, this means that there is a leak in the braking system or that the brake pads are worn beyond the limits allowed.




BRAKE FLUID

TM fills the braking systems with top quality DOT 4 brake fluid. We recommend topping up and full changes with the same type of fluid (DOT 4).

▲ DANGER

CHANGE THE BRAKE FLUID AT LEAST ONCE A YEAR. CHANGE IT MORE OFTEN IF YOU FREQUENTLY WASH YOUR MOTORCYCLE. BRAKE FLUID ABSORBS MOISTURE. THEREFORE, STEAM BUBBLES CAN FORM IN "OLD" FLUID EVEN AT LOW TEMPERATURES AND THE BRAKING SYSTEM NO LONGER WORKS CORRECTLY.





BREMBO FRONT BRAKE PUMP


ADJUSTING THE LEVER POSITION

The position of the front brake lever relative to the grip can be altered using the adjusting screw (1).

- Turn the knob (1) clockwise to move the lever away or anti-clockwise to move the lever closer.

M WARNING

When the operation is complete, check that there is 3 mm of play in the front brake lever before the brake is engaged and that the front wheel can turn freely with the lever at rest. If this play is missing, pressure builds in the braking system and the front wheel brake may fail due to overheating or the wheel locking.




CHECKING BRAKE FLUID LEVEL

The fluid reservoir is part of the front brake pump located on the handlebar and is equipped with an inspection indicator (2). With the reservoir in the horizontal position, the fluid level must never drop below the indicator center line.

▲ DANGER

IF THE BRAKE FLUID LEVEL DROPS BELOW THE MINIMUM VALUE, THIS MEANS THERE IS A LEAK IN THE BRAKING SYSTEM OR THAT THE BRAKE PADS ARE WORN BEYOND THE LIMITS ALLOWED.







TOPPING UP BRAKE FLUID


- Remove the screws (3), cover (4), and membrane (5).
- Place the reservoir in a horizontal position and top up with DOT4 brake fluid, up to the top limit of the inspection indicator (2).
- Re-fit the membrane, cover and screws and tighten them.
- Use water to wash away any brake fluid that overflowed or was spilled.

▲ DANGER


- STORE BRAKE FLUID OUT OF THE REACH OF CHILDREN.
- BRAKE FLUID MAY IRRITATE SKIN. AVOID CONTACT WITH SKIN AND EYES. IF BRAKE FLUID SPLASHES IN YOUR EYES, RINSE THOROUGHLY WITH WATER AND SEEK MEDICAL ADVICE.

M WARNING

- Prevent contact between brake fluid and painted parts. Brake fluid corrodes paint.
- Only use clean brake fluid from a hermetically sealed container.









BREMBO RADIAL FRONT BRAKE PUMP (SMR)

ADJUSTING THE LEVER POSITION

The position of the front brake lever relative to the grip can be altered using the adjusting ring (1). Turn it clockwise to move the lever away, or anti-clockwise to move the lever closer.

M WARNING

When the operation is complete, check that there is at least 3 mm of
play in the front brake lever before the brake is engaged and that the
front wheel can turn freely with the lever at rest. If this play is missing,
pressure builds in the braking system and the front wheel brake may
fail due to overheating or the wheel locking.

CHECKING BRAKE FLUID LEVEL

The fluid reservoir (2) is transparent and allows fluid level inspection. With the reservoir in an upright position, the fluid level must always be between the MAX and MIN indications.

▲ DANGER

- IF THE BRAKE FLUID LEVEL DROPS BELOW THE MINIMUM VALUE, THIS MEANS THERE IS A LEAK IN THE BRAKING SYSTEM OR THAT THE BRAKE PADS ARE WORN BEYOND THE LIMITS ALLOWED.

TOPPING UP BRAKE FLUID


Unscrew and remove the cover (3) and the membrane (4). Place the reservoir in a vertical position and top up with DOT4 brake fluid, up to the MAX limit on the reservoir. Refit the membrane and cover, then tighten them.

Use water to wash away any brake fluid that overflowed or was spilled.

▲ DANGER

- STORE BRAKE FLUID OUT OF THE REACH OF CHILDREN.
- BRAKE FLUID MAY IRRITATE SKIN. AVOID CONTACT WITH SKIN AND EYES. IF BRAKE FLUID SPLASHES IN YOUR EYES, RINSE THOROUGHLY WITH WATER AND SEEK MEDICAL ADVICE.

- Prevent contact between brake fluid and painted parts. Brake fluid corrodes paint.
- Only use clean brake fluid from a hermetically sealed container.







BREMBO 16X18 RADIAL FRONT BRAKE PUMP (SMK)

ADJUSTING THE LEVER POSITION

The position of the front brake lever relative to the grip can be altered using the adjusting wheel (1). Turn it clockwise to move the lever away, or anticlockwise to move the lever closer.

M WARNING

When the operation is complete, check that there is 3 mm of play in the
front brake lever before the brake is engaged and that the front wheel
can turn freely with the lever at rest. If this play is missing, pressure
builds in the braking system and the front wheel brake may fail due to
overheating or the wheel locking.



CHECKING BRAKE FLUID LEVEL

The fluid reservoir (2) is transparent and allows fluid level inspection. With the reservoir in an upright position, the fluid level must always be between the MAX and MIN indications.

▲ DANGER

IF THE BRAKE FLUID LEVEL DROPS BELOW THE MINIMUM VALUE, THIS
MEANS THERE IS A LEAK IN THE BRAKING SYSTEM OR THAT THE BRAKE
PADS ARE WORN BEYOND THE LIMITS ALLOWED.



TOPPING UP BRAKE FLUID

Unscrew and remove the cover (3) and the membrane (4). Place the reservoir in a vertical position and top up with DOT4 brake fluid, up to the MAX limit on the reservoir. Refit the membrane and cover, then tighten them. Use water to wash away any brake fluid that overflowed or was spilled.

A DANGER

- STORE BRAKE FLUID OUT OF THE REACH OF CHILDREN.
- BRAKE FLUID MAY IRRITATE SKIN. AVOID CONTACT WITH SKIN AND EYES. IF BRAKE FLUID SPLASHES IN YOUR EYES, RINSE THOROUGHLY WITH WATER AND SEEK MEDICAL ADVICE.

- Prevent contact between brake fluid and painted parts. Brake fluid corrodes paint.
- Only use clean brake fluid from a hermetically sealed container.






CHANGING BASIC POSITION OF REAR BRAKE PEDAL

Loosen the lower lock nut M6 (1), turn the adjusting screw using the hexagonal head (2). Once you have found the ideal position, tighten the lock nut.

The pedal play is given by the pump piston stroke. Check that the pedal has approximately 1.5 cm of play before braking starts.

MARNING

 If this play is missing, pressure builds in the braking system and braking is applied on the rear wheel. The braking system overheats and, in extreme cases, it can fail completely.




CHECKING REAR BRAKE FLUID LEVEL

The rear disc brake fluid reservoir is built into the rear brake pump. With the motorcycle upright, the level must always be over the center line of the indicator (1) on the pump body.

▲ DANGER

 IF THE BRAKE FLUID LEVEL DROPS BELOW THE MINIMUM VALUE, THIS MEANS THERE IS A LEAK IN THE BRAKING SYSTEM OR THAT THE BRAKE PADS ARE COMPLETELY WORN AWAY.



TOPPING UP REAR BRAKE FLUID


Top-up as soon as the rear brake fluid level reaches the center line of the indicator on the pump body. To do so, unscrew the two screws (1) and remove the cover (2). Top up with DOT4 brake fluid, to the end of the indicator. Re-fit the cover and tighten the screws.

Use water to wash away any brake fluid that overflowed or was spilled.

▲ DANGER

- STORE BRAKE FLUID OUT OF THE REACH OF CHILDREN.
- BRAKE FLUID MAY IRRITATE SKIN. AVOID CONTACT WITH SKIN AND EYES. IF BRAKE FLUID SPRAYS IN YOUR EYES, RINSE THOROUGHLY WITH WATER AND SEEK MEDICAL ADVICE.

- Prevent contact between brake fluid and painted parts. Brake fluid corrodes paint !
- Only use clean brake fluid from a hermetically sealed container.





CHECKING FRONT BRAKE PADS

Check the brake pads from below. The thickness of the brake pad friction material must not be less than 1 mm.


Replace the pads as soon as they reach this limit.


▲ DANGER

THE THICKNESS OF THE BRAKE PAD FRICTION MATERIAL MUST NOT BE LESS THAN 1 MM, OTHERWISE THE BRAKES MAY FAIL. REPLACE BRAKE PADS PROMPTLY TO ENSURE YOUR SAFETY.

A WARNING

If the brake pads are not replaced in time, they will be completely worn away and the steel parts of the pads will rub against the brake disc. This will significantly reduce the braking effect and deteriorate the disc.







CHECKING REAR BRAKE PADS

Check the brake pads from the rear. The thickness of the brake pad friction material must not be less than 1 mm.

Replace the pads as soon as they reach this limit.


▲ DANGER

 AT THE THINNEST POINT THE THICKNESS OF THE BRAKE PAD FRICTION MATERIAL MUST NOT BE LESS THAN 1 MM, OTHERWISE THE BRAKES MAY FAIL. REPLACE BRAKE PADS PROMPTLY TO ENSURE YOUR SAFETY.

M WARNING

- If the brake pads are not replaced in time, they will be completely worn away and the steel parts of the pads will rub against the brake disc. This will significantly reduce the braking effect and deteriorate the disc.







M WARNING

 For all models: when the pistons are returned to their standard position to make way for the new pads, make sure that the fluid in the reservoir has room to expand. Do not carry out work without the cap fitted, otherwise as it expands the fluid could overflow, damaging parts of the motorcycle.



REPLACING FRONT BRAKE PADS

FOR MODELS WITH FLOATING CALIPER (EN/MX/FT)

Take off the two clips (1), pull out pin (2) and remove the pads (3) from the caliper. Clean the brake caliper and the caliper support with compressed air. Also check that the linings of the guide pins are intact and run smoothly. Grease them if necessary.

Clean the pistons, open the pump reservoir, then push them towards the outside of the caliper to make room for the new pads.

Fit the right-hand brake pad and secure it with the pin. Fit the left-hand brake pad and insert the pin as far as the stop. Fit the clips. Make sure that while fitting the pads the sliding plate in the caliper support and the leaf spring are positioned correctly.

M WARNING

- Do not operate the brake lever while removing the pads.
- Check that the pump reservoir oil level is correct. If necessary, top up as indicated in the relevant paragraph.

FOR MODELS WITH FUSA FIXED CALIPER (SMR/SMK)

Radial connection

- Unscrew the two M10 screws (1) and remove the caliper (2) from the foot. Take out the pads (3).
- Clean the pistons, then push them towards the outside of the caliper to make room for the new pads.

M WARNING

- Do not operate the brake lever while removing the pads.
- Check that the pump reservoir oil level is correct. If necessary, top up as indicated in the relevant paragraph.
- Fit the pads correctly.
- Fit the caliper and tighten the M10 screws to 40Nm.

FOR MODELS WITH FIXED CALIPER MACHINED FROM SOLID METAL (OPT. SMK)


Radial connection


- Remove the clip (1) and extract the pin (2). Take out the worn pads.
- Clean the pistons, then push them towards the outside of the caliper to make room for the new pads.
- Insert the new pads.
- Fit the pin and the clip.

▲ DANGER


- AFTER ASSEMBLY, CHECK THAT THE SAFETY DEVICES ARE CORRECTLY POSITIONED.
- AFTER ANY WORK ON THE BRAKING SYSTEM, OPERATE THE FRONT BRAKE LEVER TO MAKE THE PADS ADHERE TO THE DISC AND CHECK THE BRAKE FLUID LEVEL AND THE PLAY.
- ALWAYS KEEP THE BRAKE DISC COMPLETELY FREE OF OIL AND GREASE, OTHERWISE THE BRAKING EFFECT WOULD BE SIGNIFICANTLY REDUCED.






















REPLACING REAR BRAKE PADS

FOR MODELS WITH FLOATING CALIPER (EN/MX/SMR/SMK)

- Open the brake pump reservoir by unscrewing the screws (1).
- Push the brake caliper (2) towards the disc, so that the piston returns to its standard position. Remove the cap (3) with a screwdriver and unscrew the pin (4) then remove the brake pads.
- Clean the pistons, then push them towards the outside of the caliper to make room for the new pads.
- Be careful of the fins (5) between the pads: they must be re-fitted with the greatest of care. Thoroughly clean the brake caliper with compressed air and check that the surface of the guide pins is intact.
- Fit the new pads, paying attention to the position of the fins. Insert the pin and tighten it. Re-fit the cap using a screwdriver. Tighten it securely.









DISASSEMBLING AND ASSEMBLING FRONT WHEEL

- Position the motorcycle with the frame cradle on a stand to keep the front wheel off the ground.
- Loosen the aluminum flanged screw (1), loosen fixing screws (2) and (3) on the left and right fork feet and finish unscrewing the flanged screw (1).
- Hold the front wheel still and slide out the wheel pin (4).
 If necessary, help the pin out by tapping the threaded end of the pin with a mallet (hammer with plastic head).

Alternatively, use a normal hammer, placing a pin punch in between.

M WARNING

Never use the hammer directly on the pin. It could cause irreversible damage.


- Carefully remove the front wheel from the fork.


MARNING


- Never operate the brake lever when the front wheel has been removed.
- Always lay the wheel flat with the brake disc upwards to avoid damaging it.
- To re-fit the front wheel, carefully insert it in the fork, ensuring that you correctly insert the disc between the brake pads without damaging them. With the wheel correctly positioned, insert the wheel pin (4), positioning the spacer (5) on the left-hand part of the wheel.
- Screw in and temporarily tighten the flanged screw (1) until the wheel shim is locked. Tighten the locking screws (2) on the right-hand fork foot to prevent the wheel pin from turning and tighten the flanged screw to 40 Nm
- Tighten the locking screws (3) on the left-hand fork foot to 12 Nm.
- Loosen the locking screws (2) on the right-hand foot again and remove the motorcycle from the stand. Operate the front brake and force the fork down several times to align its tubes.
- Definitively tighten the locking screws (2) on the right-hand fork foot to 12 Nm.

A DANGER

- IF FOR ASSEMBLY OPERATIONS YOU DO NOT HAVE A TORQUE WRENCH, GET THE TIGHTENING TORQUE CHECKED AS SOON AS POSSIBLE AT A SPECIALIZED TM WORKSHOP. AN INCORRECTLY TIGHTENED WHEEL PIN MAY MAKE THE MOTORCYCLE UNSTABLE.
- AFTER FITTING THE FRONT WHEEL, REPEATEDLY OPERATE THE BRAKE LEVER TO MAKE THE PADS ADHERE TO THE DISC AGAIN AND CHECK THE BRAKE FLUID LEVEL.
- ALWAYS KEEP THE BRAKE DISC FREE OF OIL AND GREASE. OTHERWISE THE BRAKING EFFECT WOULD BE SIGNIFICANTLY REDUCED.









DISASSEMBLING AND ASSEMBLING REAR WHEEL (EN/MX/SMR/SMK)

Position the motorcycle with the frame cradle on a stand to keep the rear wheel off the ground. Unscrew the flanged nut (1) and, holding up the wheel, slide out the wheel pin (2), remove the chain tensioner slide (3) and the caliper (4) with its support, take the chain off the sprocket, and carefully remove the rear wheel from the swing arm. Pay attention to the wheel shims (5) on the sprocket side and the brake side.

WARNING

- Never operate the brake pedal when the rear wheel has been removed.
- Always lay the wheel flat with the brake disc upwards to avoid damaging
- When the wheel pin is removed, thoroughly clean the thread of both the wheel pin and the flanged nut, and re-grease them to prevent the thread from seizing.

M WARNING

Re-fit the spacers (5) as indicated in table "A".


Table - A				
	Α	В		
SMK	16.7 mm	13.7 mm		
MX/EN/FT/SMR	13.7 mm	13.7 mm		





- To re-fit the rear wheel, insert the shim (sprocket side) in the hub, insert the wheel in the swing arm and, supporting the wheel, fit the chain on the sprocket and position the caliper (4) with its support. Insert the wheel pin (2) from the sprocket side halfway into the wheel to allow positioning of the shim (brake side).
- Push the pin in completely, insert the chain tensioner slide (3), screw on the nut (1) and tighten to 80 Nm.
- Before tightening the flanged nut, push the rear wheel forward to allow the chain tensioners to make contact with the heads of the adjusting screws.

▲ DANGER

- IF FOR ASSEMBLY OPERATIONS YOU DO NOT HAVE A TORQUE WRENCH, GET THE TIGHTENING TORQUE CORRECTED AS SOON AS POSSIBLE AT A SPECIALIZED TM WORKSHOP. AN INCORRECTLY TIGHTENED WHEEL PIN MAY MAKE THE MOTORCYCLE UNSTABLE.
- AFTER FITTING THE REAR WHEEL. REPEATEDLY OPERATE THE BRAKE PEDAL TO MAKE THE PADS ADHERE TO THE DISC AGAIN AND CHECK THE BRAKE FLUID LEVEL AND THE PLAY.
- ALWAYS KEEP THE BRAKE DISC FREE OF OIL AND GREASE, OTHERWISE THE BRAKING EFFECT WOULD BE SIGNIFICANTLY REDUCED.







4-STROKE - EN



CHECKING SPOKE TENSION

Correct spoke tension is very important for the wheel stability and for safety on the road. An insufficiently taut spoke makes the wheel unstable and will quickly loosen other spokes. Check spoke tension regularly, especially on new motorcycles. To do this, strike each spoke with the end of a screwdriver (see photo): the spoke should produce a clear sound. Hollow sounds mean that the spokes are loose. In such a case, have the spokes adjusted and the wheel centered by a specialized workshop.

▲ DANGER

- IF YOU CONTINUE TRAVELLING WITH INSUFFICIENTLY TAUT SPOKES THEY MAY BREAK, CAUSING INSTABILITY PROBLEMS.
- EXCESSIVELY TIGHT SPOKES MAY BREAK DUE TO LOCAL OVERLOADING.



TIRE PRESSURE

Tire type, condition and pressure affect motorcycle performance on the road and must therefore be checked before every ride.

- The size of the tires is indicated in the technical data and in the registration document.
- Check the condition of the tires before every ride.
 Ensure that the tires have no cuts, nails, or other sharp objects pushed
 - In terms of the minimum tread for road tires, comply with the regulations in force in your country. We recommend changing the tires not later than when the tread has reached a depth of 2 mm.
- Regularly check the pressure of "cold" tires. Correct pressure adjustment guarantees optimum comfort and maximum tire life.

▲ DANGER

- ONLY USE TIRES OF THE TYPE AND DIMENSIONS APPROVED FOR YOUR VEHICLE AND REQUIRED BY TM. DIFFERENT TIRES MAY NEGATIVELY AFFECT MOTORCYCLE PERFORMANCE ON THE ROAD AND BE THE CAUSE OF SANCTIONS UNDER THE REGULATIONS IN FORCE IN YOUR COUNTRY.
- TO GUARANTEE YOUR SAFETY AND THE SAFETY OF OTHERS, DAMAGED TIRES MUST BE REPLACED IMMEDIATELY.
- EXCESSIVELY WORN TIRES NEGATIVELY AFFECT MOTORCYCLE PERFORMANCE ON THE ROAD, ESPECIALLY ON WET SURFACES.
- INCORRECT PRESSURE LEADS TO ABNORMAL WEAR AND TIRE OVERHEATING.


TIRE PRESSURE				
	FRONT	REAR		
MX/EN off-road	1.0 bar	1.0 bar		
EN on road	1.5 bar	1.5 bar		
SMR/SMK/FT	1.8 bar	1.8 bar		



CHECKING SPEEDOMETER MAGNETIC SENSOR DISTANCE (EN/SMR)


The magnetic sensor is located on the rear wheel in all versions.

The distance between the screw heads (2) and the sensor (1) must be 2-4 mm. Otherwise speedometer operation may be irregular. The bushing (3) adjusts the sensor distance. Do not remove it, otherwise the sensor (1) would touch the screws (2) and be damaged.




REMOVING THE SEAT

- Unscrew the screws (1) from both sides.



- Lift the rear part of the seat (2).



- Pull off the seat (2) towards the back of the motorcycle.






REMOVING THE AIRBOX

- Remove the seat as indicated in the relevant paragraph.
- Unscrew the screws (1) of the right conveyor and left conveyor.





- Unscrew the screw (2) that fixes the Airbox (3) to the frame.



- Loosen the clip (4) that secures the Airbox to the throttle body.
- Lift the Airbox (3) complete with conveyors from the rear until it uncouples from the throttle body.
- Disconnect the air temperature sensor (5) and remove the whole Airbox from the motorcycle.









BATTERY

Remove the seat to access the battery.

The battery does not require maintenance.

It is not necessary to check the electrolyte level or top up with water.

Simply keep the battery poles clean and, if necessary, lightly grease them with acid-free grease.

To remove the battery, first disconnect the cable from the negative pole (-) then the cable from the positive pole (+).

Remove the battery.

To re-fit the battery, insert it lying flat, with the terminals upwards and towards the front of the motorcycle (see figure).

Connect first the cable for the positive pole (+) and then the cable for the negative pole (-).

▲ DANGER

- KEEP FAULTY BATTERIES OUT OF THE REACH OF CHILDREN AND DISPOSE OF THEM IN COMPLIANCE WITH THE REGULATIONS IN FORCE.
- AVOID ANY CONTACT BETWEEN THE POLES.

NOTE:

For more information about the battery, see the introductory part of this manual.

STORAGE

If the motorcycle is not used for a long period, remove the battery and, if necessary, maintain it using a specific battery charger for Lithium Iron Phosphate batteries. Store at a temperature between 0 and 35°C away from direct sunlight.

Charge the battery ever three or four months.

In the event of prolonged storage (eight to ten months), charge to 100%, then test the battery with a Voltmeter. For longer battery life, regular battery maintenance must be carried out.

Make sure that batteries are kept out of the reach of children.

M WARNING

- Do not use charge maintainers, battery tenders, fast chargers or other similar devices.
- Use of these devices may damage the battery, cause dangerous overheating, fires and explosions if they are not compatible.
- You must ALWAYS be present during battery charging.
- Do not charge the battery beyond the maximum voltage value indicated.

Check the external condition of the terminals and the plastic casing. Any signs of damage or unusual wear can be checked during the service. If you have any doubts about the condition of the battery, we recommend that you seek the opinion of a professional fitter.

▲ DANGER

 DO NOT REMOVE THE BATTERY COVER, AND DO NOT PIERCE OR CUT THE OUTER PLASTIC CONTAINER: RISK OF SHORT CIRCUIT.





CHARGING THE BATTERY

▲ DANGER

- WHEN CHARGING LIFEP04 BATTERIES, ONLY USE LIFEP04 BATTERY CHARGERS, SPECIFICALLY DESIGNED FOR LITHIUM ION BATTERIES.
- THE USE OF OTHER BATTERY CHARGERS COULD CAUSE DANGEROUS OVERHEATING AND EVEN BATTERY FIRES AND EXPLOSIONS.

If the battery noticeably heats up during charging, stop the charging. Allow the battery to cool before charging it. Do not under any circumstances short circuit the battery poles to check charging progress: the battery may explode.

Do not charge LIFEP04 batteries using currents higher than those indicated and recommended: it could cause dangerous overheating. To avoid creating sparks, switch off the battery charger before disconnecting its terminals from the battery.

▲ DANGER

- DO NOT CHARGE THE BATTERY BEYOND THE MAXIMUM VOLTAGE VALUE INDICATED.

NOTE: We recommend the following models for battery charging:


BRAND	MODEL	VOLTAGE	CURRENT
ALIANT	YLP14	12 V	14 Ah

The use of other battery chargers may damage the battery.

DIODE

The diode (1) is below the saddle. Its function is to protect the starter motor.


- The diode rated current is 10 A.
- Remove the saddle as indicated in the relevant paragraph.
- Disconnect the diode (1) from the connector (2) and replace it with one of equivalent value.





RECHARGE FUSE


- The fuse (1) is in the relay (2) of the electric starter motor under the seat.
- The fuse rating is 30 Amperes.
- It protects the charging and ignition systems.
- Remove the seat as indicated in the relevant paragraph.
- The starter relay (2) also holds a 30 A spare fuse (3).



ACCESSORY FUSE (EN/SMR)

- The fuse (1) is in the rubber fuse holder (2) under the seat.
- The fuse rating is 10 Amperes. It protects the lighting system, turn signals and horn.
- Remove the seat as indicated in the relevant paragraph.
- Remove the cap (1) from the fuse holder (2) and extract the fuse.

- A burnt fuse must only be replaced with another equivalent one. If the new fuse also burns out after being fitted, contact a specialized TM workshop immediately.
- Never fit a fuse that has a higher rating or attempt to "repair" the same
- Inappropriate treatments could cause faults in the entire electrical system.






ADJUSTING THE HEIGHT OF THE FRONT HEADLAMP

To check if the headlamp angle is correct, with the tires inflated to the correct pressure and someone sitting on the seat, position the motorcycle perfectly perpendicular to its longitudinal axis.

Place the bike facing a wall or screen, 10 m away from it. On the wall/ screen mark a horizontal line corresponding to the height of the center of the lamp and a vertical line aligned with the longitudinal axis of the vehicle.

Carry out the check in twilight if possible.

When you switch on the high beam the upper cutoff point between the dark zone and the lit zone must be at a height not greater than 9/10ths of the height of the center of the bulb from the ground.



LED HEADLIGHT FOR MODELS (EN/SMR)


ADJUSTING THE HEADLIGHT HEIGHT

The height of the front headlight is adjustable. Adjust the elastic straps fixing it to the forks so that the headlight is levelled frontally, then use the front screw (1) to adjust the height of the headlight. Turn clockwise to lift it, or anticlockwise to lower it.



REPLACING FRONT HEADLIGHT


- Release both elastic straps, lift and move forward the headlight holder mask.
- Completely unscrew the headlight adjusting screw (1).
- Unscrew the screws (2) and disconnect the terminals from the bike lighting system. Then remove the front headlight (3). Since this is all one unit, the whole thing must be replaced. Ask a TM dealer for the original spare part.





LED TAILLIGHT (EN/SMR)

Unscrew the screws (1) and disconnect the terminals (2) from the bike lighting system. Then remove the taillight unit. Since this is all one unit, the whole thing must be replaced. Ask a TM dealer for the original spare part.






TURN SIGNAL (EN/SMR)

Led turn signals (1)

The led turn signals must be replaced after disconnecting the motorcycle light system terminals in case of malfunction.





COOLING

The water pump (1), housed in the engine forces coolant circulation.


The system has no thermostat, therefore, it is important to limit revs and speed when the engine is cold. Proceed for at least 5 minutes at half throttle and at low speed to allow the engine to reach an adequate operating temperature.

Cooling takes place thanks to the passage of air through the radiator fins. The lower the speed, the less the cooling effect. Dirty radiator fins also reduce the cooling effect.

A valve on the radiator cap (2) adjusts the pressure produced by high fluid temperature. Temperatures close to 120°C can be reached without problems. The coolant is a mixture of 40% antifreeze and 60% water. However, the antifreeze protection limit must be at least -25°C. This mixture protects against freezing and is good for preventing corrosion. Therefore, it must not be replaced with pure water.

A WARNING

- Always use high quality products to prevent corrosion or the formation of foam.
- Overheating may occur in extreme weather or in stop-and-go traffic. To solve this problem, an electric fan kit is available as an optional accessory for models with electric start (ask your TM dealer for details).





CHECKING COOLANT LEVEL

With the engine cold, open the radiator filler cap. The fluid must cover the channels by approximately 10 mm. The radiator channels. If the level is too low, top up immediately with more fluid mix and bleed the air.

Use water only if strictly necessary and in small amounts, to avoid reducing the effective properties of the fluid.


▲ DANGER

- IF POSSIBLE, CHECK THE COOLANT LEVEL WHILE THE ENGINE IS COLD. IF YOU NEED TO OPEN THE RADIATOR FILLER CAP WHILE IT IS HOT, FIRST COVER IT WITH A CLOTH AND THEN SLOWLY OPEN IT TO DISCHARGE THE OVERPRESSURE.
 - **CAUTION: DANGER OF BURNS!**
- DO NOT DISCONNECT THE RADIATOR HOSES WHEN THE ENGINE IS HOT. LEAKING COOLANT AND HOT VAPORS CAN CAUSE SERIOUS BURNS.
- IN CASE OF BURNS, IMMEDIATELY PLACE BURNT AREAS UNDER COLD RUNNING WATER AND SEEK MEDICAL ADVICE.
- COOLANT IS TOXIC! KEEP IT OUT OF THE REACH OF CHILDREN.
- IF YOU SWALLOW COOLANT, SEEK MEDICAL ADVICE IMMEDIATELY.
- IF COOLANT GETS IN YOUR EYES, RINSE THEM IMMEDIATELY WITH COLD WATER AND SEEK MEDICAL ADVICE.

M WARNING

 Always use high quality products to prevent corrosion or the formation of foam.







DRAINING, FILLING AND BLEEDING THE COOLING SYSTEM

Coolant can be drained by removing the screw (1) from the water pump cover on the right-hand side of the engine. Have a suitable basin ready to catch the draining fluid. The radiator cap must be open in order to drain the fluid. Once finished, screw in the drain screw and tighten to 12 Nm. To fill the cooling system, pour the amount of coolant indicated in "Engine Technical Data" table in through the filler neck (2). Close the radiator cap and start the engine for a few seconds. Switch off the engine, open the cap again and check the level. Add more fluid if necessary. Go for a short ride then check the coolant level again.

250 / 300



▲ DANGER

- DRAIN THE COOLANT, IF POSSIBLE WITH THE ENGINE COLD. IF YOU NEED TO DRAIN THE COOLANT WHILE THE ENGINE IS HOT, FIRST COVER THE RADIATOR FILLER CAP WITH A CLOTH, THEN SLOWLY OPEN IT TO DISCHARGE THE OVERPRESSURE. **CAUTION: DANGER OF BURNS!**
- IN CASE OF BURNS, IMMEDIATELY PLACE BURNT AREAS UNDER COLD RUNNING WATER AND SEEK MEDICAL ADVICE.
- COOLANT IS TOXIC! KEEP IT OUT OF THE REACH OF CHILDREN.
- IF YOU SWALLOW COOLANT, SEEK MEDICAL ADVICE IMMEDIATELY.
- IF COOLANT GETS IN YOUR EYES, RINSE THEM IMMEDIATELY WITH COLD WATER AND SEEK MEDICAL ADVICE.

- After draining the coolant, when you fill up with coolant again you must bleed the cooling system.
- Always use high quality products to prevent corrosion or the formation of foam.







REPLACING EXHAUST SILENCER PACKING MATERIAL

The competition silencer is completely filled with sound absorbing material (fiberglass) to limit the motorcycle exhaust noise to within competition limits. Fiberglass tends to burn due to the high temperature reached by the exhaust fumes. This reduces both the noise absorption effect and the power. To replace the fiberglass, take the silencer off the motorcycle, removing the rivets (1) that secure the rear cap (2) to the external pipe (3). Keep the band (4) and remove the cap, leaving the internal perforated sheet metal pipe (5) in its seat. Remove the sound absorbing material to be replaced. Pack with around 450 to 500 g of TM Racing original fiberglass, inserting it in the space between the internal and external pipe with the aid of a pipe of suitable size for pushing the fiberglass into the gap, gently pressing it. Fill the gap completely.

Re-fit the front cap (2) and secure it with new rivets, taking care to position the band (4) correctly.

Mount the silencer on the bike again.


Grease the ends of the pipes to make fitting the silencer easier.

▲ DANGER

- CAUTION: DANGER OF BURNS!
- THE EXHAUST SYSTEM GETS VERY HOT WITH THE MOTORCYCLE RUNNING. TO AVOID BURNS, ALLOW THE SYSTEM TO COOL BEFORE STARTING WORK ON IT.
- IN CASE OF BURNS, IMMEDIATELY PLACE BURNT AREAS UNDER COLD RUNNING WATER AND SEEK MEDICAL ADVICE.

M WARNING

- Replace the fiberglass with new product purchased from TM dealers or, if that is not possible, with an equivalent product.
- Never use flammable material to pack the silencer.





4 • MAINTENANCE




CLEANING AIR FILTER

Regularly clean and maintain the air filter.

A dirty air filter compromises air flow, reduces motorcycle power and increases fuel consumption. In some cases, dust may enter the engine and cause serious damage. Therefore, regular air filter maintenance is necessary.


- Turn the screw (1) 1/4 of a turn.



- Lift the filter cover (2) and remove it.



Unscrew the butterfly screw (3) and remove it.



- Carefully take the filter (4) out of the seat.






- Separate the sponge element (5) from the plastic cage (6). Carefully wash the sponge element with the special detergent and allow it to air dry completely. If necessary, gently squeeze the sponge but never wring it. Clean the plastic cage and the filter case and check that the sleeve connecting the throttle body to the filter case is intact and positioned correctly.
- Oil the cage with filter oil, then put the sponge and cage back together.
 Re-fit the air filter, positioning it correctly on the supporting surface.
 Ensure that the edges of the sponge are not lifted or non-adhering to the supporting surface.
- Tighten the butterfly screw (3) again.
- Put the filter cover (2) back on.

A WARNING

- Do not clean the sponge element with petrol or oil, since they may corrode it. For correct maintenance, use the specific products available on the market for cleaning and lubrication.
- Never start the motorcycle without the air filter in place. Dust and dirt infiltration may cause damage and high levels of wear.
- Make sure that there is a perfect seal between the sleeve and the filter case. Also ensure that the sponge element is correctly fitted on the plastic cage. Any leaks may allow sand or dirt into the engine.






CHOKE (450 SMR/EN)

The choke lever must have 1 - 15 mm of play. To adjust play, proceed as follows:

- move the protective cap (1) on the throttle body;
- loosen the lock nut (2) and turn the adjusting screw (3) to obtain the required play. Tightening the screw (3) increases play.





ADJUSTING THROTTLE CONTROL CABLES

Adjustment on these models must be performed on the throttle body. The throttle grip must be adjusted to suit the rider, but must always have at least 1 - 2 mm of play.

- To adjust the play, move the protective caps (1).
- First adjust the (upper) opening cable, then the (lower) closing cable.
 Consult the information on the sheaths.

Opening cable


- Loosen the lock nut (2) and tighten or loosen the adjusting screw (3) to obtain the required play.
- Tightening the adjusting screw increases play.
- Loosening the adjusting screw reduces play.
- Tighten the lock nut and check that the grip rotates smoothly.

Closing cable

- Loosen the lock nut (4) and tighten or loosen the adjusting screw (5) to obtain the required play.
- Tightening the adjusting screw increases play.
- Loosening the adjusting screw reduces play.
- Tighten the lock nut and check that the grip rotates smoothly.
- Put the protective caps back in place.

A WARNING

- With the engine running, ensure that the idle speed is correct and does not increase when you steer all the way right or left.



ADJUSTING IDLE SPEED

Adjusting idle speed has a big impact on engine starting. That is to say, an engine with correct idle speed adjustment will be easier to start than an engine with incorrect idle speed.

Every TM Racing bike is delivered with an idle speed adjustment suitable for the type of motorcycle. This adjustment can be changed if necessary. With the engine running, warm enough and without touching the throttle grip, turn the knob (1) located on the left-hand side of the bike. Turn it clockwise to increase the idle speed, or anti-clockwise to reduce it.

Do not set the idle speed too low. If you have a rev counter, never go below 2500 rpm for 250 / 300 cc and 2200 rpm for 450 cc with the engine warm.

Instead of a rev counter, you can use the TM Moto diagnosis and programming "PDA".

A WARNING

 Never adjust the idle speed with the engine off. You risk not being able to start the engine again.





OIL CIRCUIT (250 - 300)

The delivery pump (1) sucks in engine oil through the plastic mesh filter (2) from the primary gearbox - transmission compartment (3) which also serves as an oil sump. The oil is sent under pressure through a duct (4) to the cartridge filter (5), where all impurities are removed. Part of it is then sent to the crankshaft and part to the timing system.

The oil sent to the crankshaft enters a duct made in the shaft and lubricates the big end bearing (6).


The oil sent to the timing system is carried to the top of the crankcase and branches further before entering the cylinder.

A nozzle directs part of it towards the small end (7), to lubricate the piston ring.

The other part is channeled along the cylinder and through suitable holes to the nozzles that lubricate the contact points (8 and 9) between the cams and rockers and between the rockers and valve pads.

All of the oil delivered under pressure to the main engine parts then falls and is sucked to the point where the draining pump (10) recovers it and sends it back to the gearbox - transmission compartment (3).

Oil circulates only in channels made in the engine, without the use of any external pipes.



OIL CIRCUIT (450)

The delivery pump (1) sucks in engine oil through the metal mesh filter (2) from the oil sump (3). The oil is sent under pressure through a duct (4) to the cartridge filter (5), where all impurities are removed. Part of it is then sent to the crankshaft, and part to the timing system and the gearbox.

The oil sent to the crankshaft enters a duct made in the shaft and lubricates the big end bearing (6).

The oil sent to the timing system and the gearbox is carried to the top of the crankcase and branches further before entering the cylinder.

Part of it is channeled to the gearbox and, through a distributor (10) lubricates the gear teeth. Part of it goes through the primary shaft (11).


A spray nozzle directs another part of the oil towards the small end (7), to lubricate the piston ring.

Finally, another part is channeled along the cylinder and through suitable holes to the smooth bearings of the camshafts and to the point of contact between the cams and cups (8 and 9).

All of the oil delivered under pressure to the main engine parts then falls and is sucked to the point where the draining pump (12) recovers it and sends it back to the oil sump.

Notice that the oil sump is separate from the engine rotating parts (e.g.: dry casing) but is integrated in the crankcase casting.

Plus, oil circulates only in channels made in the engine, without the use of any external pipes.





ENGINE OIL

Only use high quality engine oil, of the type indicated in the "Technical data" section.

CHECKING ENGINE OIL LEVEL (250 - 300)

Position the motorcycle on a flat surface and keep it upright (not leaning on the side stand).

With the engine off, check for the presence of oil by looking at the level indicator (1) on the right-hand side of the engine. If you cannot see oil, tilt the motorcycle to the right for several seconds and check the indicator again. If you still do not see any oil, top up 100 cc at a time until it is visible. Use the same type of oil as that already in the engine.

Start the motorcycle and keep it at a constant speed just above idle speed for 2 minutes. Turn off the engine and allow the oil to settle for another 2 minutes. The oil level must be approximately halfway up the level indicator on the right-hand side of the bike.

If the level is near the lower part of the indicator, or even not visible, immediately top up 100 cc at a time using the same type of oil as that already in the engine. Then repeat the check.



TOPPING UP ENGINE OIL (250 - 300)

Unscrew the oil cap (2) on the right-hand side of the engine (clutch cover) and use a measuring cup to pour in the necessary amount of oil. Check the seal gasket, replacing it if necessary. Then tighten the cap again to 20 Nm.

- A level that is too low, poor quality oil or longer maintenance intervals than scheduled cause serious engine damage.
- Never pour too much oil into the engine. If this happens, drain it as described in the "Changing engine oil and filter" section.





CHECKING ENGINE OIL LEVEL (450)

Position the motorcycle on a flat surface and keep it upright (not leaning on the side stand).

Start the motorcycle and keep it at a constant speed just above idle speed. The oil level must be visible at between half and 3/4 of the way up the level indicator (1) on the right-hand side of the engine.

If the level is near the lower part of the indicator, or even not visible, immediately top up 100 cc at a time using the same type of oil as that already in the engine. Then repeat the check.


TOPPING UP ENGINE OIL (450)

Unscrew the oil cap (2) on the left-hand side of the engine and use a measuring cup to pour in the necessary amount of oil. Check the seal gasket, replacing it if necessary. Then tighten the cap again to 20 Nm.

A WARNING

- A level that is too low, poor quality oil or longer maintenance intervals than scheduled cause serious engine damage.
- Never pour too much oil into the engine. If this happens, drain it as described in the "Changing engine oil and filter" section.








CHANGING ENGINE OIL AND FILTER (250 - 300)

The oil must be changed with the engine off, but still warm enough to allow the used oil to drain more easily.

- Unscrew the four screws (A) and remove the engine cover (B).





- Position the motorcycle on a flat surface and place a suitable basin under the engine. Unscrew the oil filler cap (1) on the right-hand side of the engine (clutch cover) and the drain caps (2 and 3) on the lower side of the engine, allowing the oil to drain into the basin.
- In the meantime, remove the filter cover (4) on the right-hand side of the engine by unscrewing the relative screws. Take care to catch any oil that comes out.
- Take out the cartridge filter (5) and clean the surfaces of the casing and the filter cover. Check the seal O-rings (6 and 7), replacing them if necessary. Insert a new original TM Racing filter, with the open side towards the outside of the engine. Press the filter all the way into its seat.
- Re-fit the O-rings and the filter cover, tightening the screws to 8 Nm.
- Wait until all of the oil has drained from the drainage holes. Then clean the seal surfaces, check the gaskets, clean any debris from the drainage cap magnets (8) and screw on the caps again, tightening them to 20 Nm.
- Prepare a measuring cup with the necessary amount of engine oil of the required type (see table) and pour it into the filler hole.
- Check the seal gasket, replacing it if necessary. Then tighten the cap again to 20 Nm.
- Repeat the oil level check.
- Check the seal of the oil filler and drainage caps and of the filter cover.

▲ DANGER

BEWARE OF HOT OIL AND ENGINE PARTS. RISK OF BURNS.

A WARNING

- A level that is too low, poor quality oil or longer maintenance intervals than scheduled cause serious engine damage. Never pour too much oil into the engine. If this happens, drain it as described above.
- When changing the oil always replace the filter too. If you do not have a new filter, remove the used one to inspect it and drain the used oil from its seat. Re-fit it by following the procedure described.
- Do not attempt to clean a used filter.


ENGINE OIL QUANTITY TABLE


Oil and filter change	1.25 l
Oil change and filter inspection	1.25 l
Engine overhaul	1.35 l


NOTE:

For the type of oil to be used, see the "Technical data" section.

















CHANGING ENGINE OIL AND FILTER (450)


The oil must be changed with the engine off, but still warm enough to allow the used oil to drain more easily.

- Unscrew the four screws (A) and remove the engine cover (B).
- Position the motorcycle on a flat surface and place a suitable basin under the engine. Unscrew the oil filler cap (1) on the left-hand side of the engine and the drain cap (2) on the lower side of the engine, allowing the oil to drain into the basin.
- In the meantime, remove the filter cover (3) on the right-hand side of the engine, taking care to catch any oil that comes out.









4 • MAINTENANCE



- Take out the cartridge filter (4) and clean the surfaces of the casing and the filter cover. Check the seal O-rings (5 and 6), replacing them if necessary.
- Insert a new original TM Racing filter, with the open side towards the outside of the engine. Press the filter all the way into its seat.
- Re-fit the O-rings and the filter cover, tightening the screws to 8 Nm.
- Wait until all of the oil has drained from the drainage hole. Then clean the seal surface, check the gasket, clean any debris from the drainage cap magnet and screw on the cap again, tightening it to 20 Nm.
- Prepare a measuring cup with the necessary amount of engine oil of the required type (see table) and pour approximately 0.8 l into the filler hole
- Temporarily close the oil filler cap, start the engine and run it for around 5 seconds. To avoid damage, do not run the engine any longer than that.
- Open the oil filler cap again and finish filling up with the oil remaining in the measuring cup.
- Screw on the cap and tighten it to 20 Nm.
- Repeat the oil level check.
- Check the seal of the oil filler and drainage caps and of the filter cover.

▲ DANGER

- BEWARE OF HOT OIL AND ENGINE PARTS. RISK OF BURNS.

A WARNING


- A level that is too low, poor quality oil or longer maintenance intervals than scheduled cause serious engine damage.
- Never pour too much oil into the engine. If this happens, drain it as described in the "changing engine oil (450 all 530 all)" section.
- When changing the oil always replace the filter too. If you do not have a new filter, remove the used one to inspect it and drain the used oil from its seat. Re-fit it by following the procedure described.
- Do not attempt to clean a used filter.

ENGINE OIL QUANTITY TABLE

Oil and filter change	1.40 l
Oil change and filter inspection	
Engine overhaul	1.50 l

NOTE

For the type of oil to be used, see the "Technical data" section.







5. DIAGNOSIS









Performing the scheduled maintenance on your motorcycle will make encountering problems unlikely. However, should a problem occur, check the troubleshooting table and follow the instructions provided to solve the problem.

The table includes two columns indicating who should perform the work:



• the symbol means that the work must be done by the user;

 the symbol means that the work must be done by a technician or at an authorized TM workshop.

Therefore, for your safety, have such work done only at a specialized TM workshop, so that your motorcycle is serviced optimally by specifically trained personnel. Contact a TM dealer if you have any questions. For anything not covered here, consult the "PDA" section.

PROBLEM	CAUSE	SOLUTION	Ä	
	Incorrect command (EN/SMR).	Correctly repeat the procedure to activate the starter motor according to the motorcycle model.	•	
	Ignition key not inserted or not turned (SMR).	Insert the ignition key and turn it clockwise.	•	
	Incorrect command (MX and SMK).	Correctly repeat the procedure to activate the starter motor according to the motorcycle model.	•	
ENGINE DOES NOT TURN OVER	Faulty start relay.	Check the start relay and replace it.		•
(MODELS WITH E.S.)	Discharged battery.	Charge the battery and find the cause of discharging.		•
	Ambient temperature very low.	Start the engine using the kick starter vigorously.	•	
	Faulty starter motor.	Check the starter motor.		•
	Burnt out 30A fuse	Check the fuse and replace it if necessary	•	



PROBLEM	CAUSE	SOLUTION	4	
	Incorrect command.	Correctly repeat the engine start procedure according to the motorcycle model.		
	No fuel supply to the engine.	Refuel. Check the petrol pump connections and fuel pipe.	•	
	Incorrect idle speed adjustment.	Check fuel pressure. Correctly adjust the idle speed.	•	•
	Flooded engine.	Follow the hot start procedure.	•	
ENGINE TURNS OVER	Wet spark plug.	Clean and dry the spark plug or replace it if required.	•	
BUT FAILS TO START	Incorrect distance between electrodes.	Adjust the distance between electrodes to 0.8 mm.	•	
	Faulty ignition system.	Check the ignition system (PDA).		•
	Faulty injection system.	Check the injection system (PDA).		•
	Damaged wiring.	Check the wiring, earth connections, connector integrity, cables and sheaths		•
	Damaged spark plug cap.	Check the spark plug cap and replace it if required.	•	
	Faulty stop switch (EN/ SMR).	Check the start and stop switch.		•
	Faulty engine stop button (MX / SMK).	Check the engine stop button.		•
	Incorrect idle speed adjustment.	Correctly adjust the idle speed.	•	
ENGINE DOES NOT KEEP RUNNING AT	Damaged spark plug.	Replace the spark plug.	•	
IDLE	Faulty ignition system.	Check the ignition system (PDA).		•
	Insufficient valve clearance.	Adjust valve clearance.		•
	Faulty ignition system.	Check the ignition system (PDA).		•
ENGINE DOES NOT REACH FULL SPEED	Faulty injection system.	Check the injection system (PDA).		•
	Faulty ECU (engine control unit).	Replace the ECU.		•

4-STROKE - (EN) _______ 5•114 _____



PROBLEM	CAUSE	SOLUTION	Ä	
	Clogged air filter.	Clean or replace the air filter.	•	
	Faulty injection system.	Check the injection system (PDA).		•
INSUFFICIENTENGINE	Exhaust system not sealed, deformed or silencer fiberglass needs replacing.	Check the faulty parts on the exhaust system, replace the fiberglass in the exhaust silencer.		•
POWER	Insufficient valve clearance.	Adjust valve clearance.		•
	Faulty ignition system.	Check the ignition system (Diagnostic Tool).		•
	Faulty ECU (engine control unit).	Replace the ECU.		•
	Clogged fuel filter.	Replace the fuel filter.		•
		Refuel.	•	
	No fuel supply to the engine.	Check the petrol pump connections and fuel pipe.	·	
ENGINE MISFIRES OR		Check fuel pressure.		•
SWITCHES OFF WHILE	Damaged spark plug.	Replace the spark plug.	•	
RUNNING	Faulty ignition system.	Check the ignition system (Diagnostic Tool).		•
	Faulty injection system.	Check the injection system (Diagnostic tool).		•
	Faulty ECU (engine control unit).	Replace the ECU.		•
ENGINE OVERHEATS	Insufficient fluid in the cooling system.	Check and top-up the coolant level. Check the seal of the cooling system.	•	
	Insufficient ventilation.	Ride for a while on a flat road at moderate speed without stressing the engine (you can fit an optional electric fan).	•	
EXCESSIVELY	Air in cooling circuit.	Bleed the cooling system.	•	
	The radiator fins are very dirty.	Clean the radiator fins with water (not under pressure).	•	
	Formation of foam in the cooling system.	Replace the coolant using a good brand of anti-freeze.	•	
LIGHTS, SPEEDOMETER, HORN AND TURN SIGNALS DO NOT WORK	Burnt out accessory fuse.	Check the 10A accessory fuse and replace it.	•	
BATTERY IS DISCHARGED EVEN	The battery is not charged by the generator.	Check the generator and voltage regulator.		•
IF THE MOTORCYCLE HAS BEEN USED RECENTLY	The battery is damaged.	Replace the battery.		•

5 • DIAGNOSIS




CONNECTING OBD TOOL

- The socket for connecting this tool is on the left of the motorcycle, below the Airbox.
- Take out the socket (1), remove the protective cap (2) and connect the tool.

M WARNING

After making the required adjustments, put the protective cap (2) back on the socket (1).





CALTOOL MANUAL

Installing and running for the first time

To use the diagnostic software, the following is required:

- 1 Computer with 64-bit Windows 10 operating system or higher
- 1 USB port


The program is compatible with all vehicles equipped with the "eMoticom" engine control unit

NOTE: All vehicles equipped with other control units are incompatible.


Once installed, the program also works offline.

Download the software:

- The dedicated link is required to download the program
- Open the link in a web browser:



- Click the green "Download" button; the entire folder will automatically start downloading in .Zip format.
- When it has finished downloading, unzip the newly downloaded folder and copy it to your "Documents" folder




- 5•117 **-**

5 • CALTOOL DIAGNOSIS



Installing the program

- Open the Documents/Emoticom/Software folder, and use the right mouse button to select: "Run as administration" on the eMoticom_CalTool executable file



A WARNING

If you do not install the program in this way, it is unlikely to work



- Press "Next" until the program installation has finished.




After installation, you will find the program icon on your Desktop.

4-STROKE - EN



Installing the driver


- Open the Documents/Emoticom/Software/Driver USB folder, and use the right mouse button to select: "Run as administration" on the CDM21228_Setup.exe executable file



Proceed until installation is complete, after which you will be able to connect the diagnostic key to the computer.

Running the program for the first time

When running Caltool for the first time, the following screen will appear:



5•119 -


If the files have been copied successfully, the available templates will be displayed.

______ (EN) - 4-STROKE

5 • CALTOOL DIAGNOSIS




- Select the specific file for your vehicle (e.g. EN 250Fi ES 2025 Template 2.14)
- To change the selected Template, press "Interface" in the top menu and select "Load new ECU Template"



The same page as opened initially will be displayed, after which repeat the Template loading steps explained above.

Loading a Workspace

- To select a Workspace (the workspace file includes all the widgets useful for diagnosing motorcycles), press "Interface" in the top menu, and select "Load Layout" followed by "Workspace"



4-STROKE - EN



SOFTWARE USER GUIDE

Tab and Layout management guide

The controls at the top of the toolbar are divided by category:

- File: to load and save mapping files;
- Communication: to manage communication with the control unit;
- Workspace: for checks with the interface;
- Tools: containing the 'codeLoad' tool to update the control unit firmware.
- Interface: To load Templates and lock the side menu closed



The status bar at the bottom contains (left to right):

- ECU Disconnected/Connected: Connection status between the software and control unit (red not connected, green connected). If the connection is working correctly, the control unit firmware version will appear on the screen;
- The name of the Configuration file currently loaded in the ECU;
- The name of the Map file currently loaded in the ECU;
- A series of warnings indicating the control unit status;



The names of the configuration and map files currently opened by the software are displayed on the title bar. From the left bar you can select widgets to add to the current TAB.



Communication with the control unit

To communicate with the ECU, the EM008 CAN-USB adapter must be connected to the PC and the corresponding diagnostic connector on the motorcycle.



Press the "Connect ECU" button (at the top left) to connect to the control unit; the word "Connected" at the bottom left turns green when the control unit is connected correctly.


You can now access the receive and transmit menu RX TX on the function control bar.

5 • CALTOOL DIAGNOSIS




Correcting a Map

You can make changes to the loaded map file using the following functions: Gear parameters: to change gearbox configurations or update quickshifter thresholds;




Injection auxiliary correction: to make corrections within the ranges pre-set in the program:

- A value of 1000 indicates the default amount of petrol.
- It can be made up to 30% richer (1300) and up to 30% leaner (0.700); the engine rpm threshold and % throttle opening can also be varied by changing the value in the main column.
- Changed values remain highlighted with a different colour.



Engine parameter check

The side menu contains the `general monitor' and `analog inputs' sections, where you can access the controls to check the motorcycle parameters.






Vehicle maintenance

The 'manual adjustments' section of the side menu contains widgets to assist with motorcycle maintenance:


- Maintenance widget: checks to calibrate the exhaust valve and purge the oil pump;
- Output test widget: checks to test the various motorcycle actuators (injectors, spark plugs, oil and petrol pumps, cooling fan).



Diagnostics and OBD

There are three ways to perform vehicle diagnostics from the OBD Warning Tab:

• From the 'Engine diagnostics' function, you can see the control unit operating hours count and reset the partial counts;




5•123 -


EN - 4-STROKE



• From the 'Actuators faults' function, you can see the error status of the motorcycle actuators to reset them;




• From the 'OBD names' function, you can see the name transmitted by the control unit on the OBD BUS (you have to press the update button).





Updating the Firmware


- To update the firmware (if necessary), press "Tools", "Code Load".



A window will open:

- Check that the words "ECU Connected" appear in orange to confirm that the ECU is connected.






CORRECT ERROR


5 • CALTOOL DIAGNOSIS



- Press "ReBoot to Code Load" to reboot the control unit, after which you can press the "Send" button and select the next firmware.




- Select the appropriate firmware from the window that opens.





The procedure will take a few minutes; press OK once loading has finished.



- To return to normal mode, press the 'reboot to app' button and close the window. "In some cases, you have to re-select the correct Template after changing the firmware."

A WARNING

Check that the battery is charged properly, and do not disconnect the control unit for any reason while the firmware is being rewritten as doing so could cause the control unit to crash.

5•127 -















ENGINE TECHNICAL DATA EN - SMR 250 - 300 - 450				
MOTORCYCLE MODEL	EN 250	EN 300	SMR - EN 450	
Туре		Twin cam single cylinder	4-stroke, liquid-cooled	
Displacement	249 cc	299 сс	449 cc	
Bore/stroke	77x53.6 mm	81x58.1 mm	95x63.4 mm	
Compression	14 : 1	13.7 : 1	12.9 : 1	
Fuel	RO	N 95 super unleaded fue	l (ethanol allowed <10%)	
Timing system	4 c	overhead valve twin cam	driven by silenced chain	
A / S camshafts	XA19/	/XS04	N2 / N3	
Suction valve diameter	32 m	nm Ti	36 mm	
Exhaust valve diameter	26.8 r	mm Ti	31 mm	
Cold suct. valve clearance	0.10	mm	0.15 mm	
Cold exh. valve clearance	0.15	5 mm	0.20 mm	
Engine shaft supports	2 roller h	bearings	2 ball bearings	
Small end bearing		Bearii	ng	
Pin coating		DLC	,	
Piston	forged light alloy		nt alloy	
Segments		1 segment + 1 oil scraper		
Lubrication	2 oil pumps (1 for delivery + 1 for recovery)		ery + 1 for recovery)	
Engine oil	SAE 10W/50		N/50	
Engine oil amount (oil change / engine overhaul)	1.25 / 1.4 liters		1.4 / 1.5 liters	
Straight tooth gear primary transmission	18 / 59	20 / 59	20 / 57	
Clutch		with multiple dis	cs in oil bath	
Gearbox (with front couplings)	6 g€	ears	6 gears	
Gear ratios 1st 2nd 3rd 4th 5th 6th	(250) 14:30 16:28 20:29 22:27 24:25 20:19	(300) 13:31 15:27 16:23 20:24 20:21 22:20	(450) 1-13:30 2-16:26 3-19:24 4-20:21 5-18:16 6-23:18	
Generator	12V 180W		0W	
NGK spark plug	RO451B-8		CR 9EIX	
Electrode distance		0.8 m	m	
Cooling	fluid, 40% antif	reeze, 60% water (up to	-25°C) - circulation forced with pump	
Fluid amount	1 li	iter	1.3 liters	
Start		ES (KS op	otional)	

- 6•131 **-**

LEGEND:

ES = Electric start **KS** = Kick start



TECHNICAL DATA ENGINE MX 250 - 300 - 450 - SMK 250			
MOTORCYCLE MODEL	MX - SMK 250	MX 300	MX 450
Туре	Twin cam single cylinder 4-stroke, liquid-cooled		
Displacement	249 cc	299 сс	449 cc
Bore/stroke	77x53.6 mm	81x58.1 mm	95x63.4 mm
Compression	14 : 1	13.7 : 1	12.9 : 1
Fuel	RO	N 95 super unleaded fuel	(ethanol allowed <10%)
Timing system	4 c	overhead valve twin cam	driven by silenced chain
A / S camshafts	XA16/XS04	XA18/XS04	FA10/FS4
Suction valve diameter	32 m	nm Ti	36 mm Ti
Exhaust valve diameter	26.8 ı	mm Ti	31 mm
Cold suct. valve clearance	0.10	mm	0.15 mm
Cold exh. valve clearance	0.15	5 mm	0.20 mm
Engine shaft supports	2 roller l	pearings	2 ball bearings
Small end bearing		Bearir	ng
Pin coating		DLC	
Piston	forged light alloy		
Segments	1 segment + 1 oil scraper		oil scraper
Lubrication	2 oil pumps (1 for delivery + 1 for recovery)		ry + 1 for recovery)
Engine oil	SAE 10W/50		
Engine oil amount (oil change / engine overhaul)	1.25 / 1.4 liters 1.4 / 1.5 liters		1.4 / 1.5 liters
Straight tooth gear primary transmission	17 / 60	20 / 59	20 / 57
Clutch		with multiple disc	es in oil bath
Gearbox (with front couplings)	6 gears (on re	quest 5 gears)	5 gears
Gear ratios 1 st 2 nd 3 rd 4 th 5 th 6 th	14:30 16:28 20:29 22:27 24:25 22:20	13:31 15:27 16:23 20:24 20:21 20:19 (elim. per 5M)	16:27 17:24 16:19 21:21 23:20
Generator		12V 80	W
NGK spark plug		R0451E	3-8
Electrode distance		0.8 mi	n
Cooling	fluid, 40% antif	reeze, 60% water (up to -	25°C) - circulation forced with pump
Fluid amount	1 li	ter	1.3 liters
Start		ES (KS op	tional)

LEGEND:

ES = Electric start

KS = Kick start

4-STROKE - (EN) 6-132 -



	TECHNICAL DATA ENGINE SMK 250 - 300 - 450	
MOTORCYCLE MODEL	450	
Туре	Twin cam single cylinder 4-stroke, liquid-cooled	
Displacement	449 cc	
Bore/stroke	95x63.4 mm	
Compression	13.2 : 1	
Fuel	RON 95 super unleaded fuel (ethanol allowed <10%)	
Timing system	4 overhead valve twin cam driven by silenced chain	
A / S camshafts	FA11/FS12	
Suction valve diameter	39 mm Ti	
Exhaust valve diameter	32 mm Ti	
Cold suct. valve clearance	0.15 mm	
Cold exh. valve clearance	0.20 mm	
Engine shaft supports	2 ball bearings	
Small end bearing	Bearing	
Pin coating	DLC	
Piston	forged light alloy	
Segments	1 segment + 1 oil scraper	
Lubrication	2 oil pumps (1 for delivery + 1 for recovery)	
Engine oil	SAE 10W/50	
Engine oil amount (oil change / engine overhaul)	1.4 / 1.5 liters	
Straight tooth gear primary transmission	19 / 57	
Clutch	with multiple discs in oil bath	
Gearbox (with front couplings)	6 gears	
Gear ratios	1 st 16:27 2 nd 17:24 3 rd 16:19 4 th 21:22 5 th 23:21 6 th 24:20	
Generator	12V 80W	
NGK spark plug	R0451B-8	
Electrode distance	0.8 mm	
Cooling	fluid, 40% antifreeze, 60% water (up to -25°C) - circulation forced with pump	
Fluid amount	1.3 liters	
Start	ES (KS optional)	

LEGEND:

ES = Electric start

KS = Kick start



	TECHNICAL DATA - ENGINE FT 450
MOTORCYCLE MODEL	450
Туре	Twin cam single cylinder 4-stroke, liquid-cooled
Displacement	449 cc
Bore/stroke	95x63.4 mm
Compression	13.2 : 1
Fuel	RON 95 super unleaded fuel (ethanol allowed <10%)
Timing system	4 overhead valve twin cam driven by silenced chain
A / S camshafts	FA11/FS12
Suction valve diameter	39 mm Ti
Exhaust valve diameter	32 mm Ti
Cold suct. valve clearance	0.15 mm
Cold exh. valve clearance	0.20 mm
Engine shaft supports	2 ball bearings
Small end bearing	Bearing
Pin coating	DLC
Piston	forged light alloy
Segments	1 segment + 1 oil scraper
Lubrication	2 oil pumps (1 for delivery + 1 for recovery)
Engine oil	SAE 10W/50
Engine oil amount (oil change / engine overhaul)	1.4 / 1.5 liters
Straight tooth gear primary transmission	20 / 57
Clutch	with multiple discs in oil bath
Gearbox (with front couplings)	5 gears
Gear ratios 1st 2nd 3rd 4th 5th	16:27 17:24 16:19 21:21 23:20
Generator	12V 80W
NGK spark plug	R0451B-8
Electrode distance	0.8 mm
Cooling	fluid, 40% antifreeze, 60% water (up to -25°C) - circulation forced with pump
Fluid amount	1.3 liters
Start	ES (KS optional)

LEGEND:

ES = Electric start

KS = Kick start



CHASSIS TECHNICAL DATA EN 250 - 300 - 450				
MOTORCYCLE MODEL	250	300	450	
Frame	High r	High resistance aluminum alloy perimeter		
Front suspension		Kayaba USD Ø 48 mm fork		
Front/rear suspension stroke		front 310mm - rear 320 mm	1	
Rear suspension	Aluminum swing arm, Pro	ogressive linkage, TM Moto S	Shock absorber	
Front disc brake		Ø 270 mm floating caliper		
Rear disc brake		Ø 245 mm floating caliper		
Front/rear brake disc wear limit	min 3.5 mm			
Front tire	90/90 - 21" (100/80 - 21" OPT)			
Air pressure	1.0 bar (off-road) / 1.5 bar (on road)			
Rear tire	120/90 - 18"	140/80 - 18"	140/80 - 18"	
Off-road air pressure	1.0 bar (off-road) / 1.5 bar (on road)			
Tank capacity		8 liters		
Chain	114 O-Ring	114 rx O-Ring 5/8 x 1/4"	116 O-Ring	
Optional sprockets	48, 49, 50, 51, 52, 53			
Bulbs	High/low beam			
Battery		12V - 50Wh - EQ - 14h		

CHASSIS TECHNICAL DATA SMR 250 - 300 - 450			
MOTORCYCLE MODEL	450		
Frame	High resistance aluminum alloy perimeter		
Front suspension	Kayaba USD Ø 48 mm fork		
Rear suspension	Aluminum swing arm, Progressive linkage, TM Moto Shock absorber (optional Ohlins TTX)		
Front disc brake	Ø 306 mm 4-piston caliper		
Rear disc brake	Ø 245 mm floating caliper		
Front brake disc wear limit	min. 4.5 mm		
Rear brake disc wear limit	min. 3.5 mm.		
Front tire	120/70 x 17"		
Air pressure	1.8 bar		
Rear tire	150/60 - 17"		
Off-road air pressure	1.8 bar		
Tank capacity	8 liters		
Chain	5/8 x 1/4"		
Optional sprockets	39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49		
Bulbs	High/low beam		
Battery	12V - 50Wh - EQ - 14Ah		



CHASSIS TECHNICAL DATA MX 250 - 300 - 450			
MOTORCYCLE MODEL	250	300	450
Frame	High re	esistance aluminum alloy pe	rimeter
Front suspension		Kayaba USD Ø 48 mm fork	
Front/rear suspension stroke		front 310 mm - rear 320 mm	1
Rear suspension	Aluminum swing arm	Progressive linkage, TM R	acing Shock absorber
Front disc brake		Ø 270 mm floating caliper	
Rear disc brake	Ø 245 mm floating caliper (Ø 205 mm optional)		
Front/rear brake disc wear limit	min. 3.5 mm		
Front tire	80/100 x 21"		
Air pressure		1.0 bar	
Rear tire	100/90 - 19" 110/90 - 19"		110/90 - 19"
Off-road air pressure	1.0 bar		
Tank capacity	6.75 liters		
Chain	5/8 x 1/4"		
Optional sprockets	48, 49, 50, 51, 52, 53		
Battery	12V - 24Wh - EQ - 5Ah		

CHASSIS TECHNICAL DATA SMK 250 - 300 - 450			
MOTORCYCLE MODEL	450		
Frame	High resistance aluminum alloy perimeter		
Front suspension	Kayaba USD Ø 48 mm fork		
Front/rear suspension stroke	front 280 mm - rear 300 mm		
Rear suspension	Aluminum swing arm, Progressive linkage, TM Moto Shock absorber (optional Ohlins TTX)		
Front disc brake	Ø 306 mm floating caliper		
Rear disc brake	Ø 245 mm floating caliper (Ø 205 mm optional)		
Front brake disc wear limit	min. 4.5 mm		
Rear brake disc wear limit	min. 3.5 mm.		
Front tire	120/70 x 16.5 - 3.50" (optional TBL STS Alpina 16/16.5 - 3.50")		
Air pressure	1.8 bar		
Rear tire	160/60 - R17 (optional TBL STS)		
Off-road air pressure	1.8 bar		
Tank capacity	8 liters		
Chain	110 rx 5/8 x 1/4"		
Optional sprockets	39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49		
Battery	12V - 50Wh - EQ - 14Ah		

4-STROKE - (EN) — 6•136 -



CHASSIS TECHNICAL DATA FT 450			
MOTORCYCLE MODEL	450		
Frame	High resistance aluminum alloy perimeter		
Front suspension	Kayaba USD fork		
Front/rear suspension stroke	front 180 mm - rear 260 mm		
Rear suspension	Aluminum swing arm, Progressive linkage, TM Moto Shock absorber		
Front disc brake	Ø 270 mm floating caliper		
Rear disc brake	Ø 245 mm floating caliper		
Front/rear brake disc wear limit	min 3.5 mm		
Front tire	270/70 19"		
Air pressure	-		
Rear tire	275/75 19"		
Off-road air pressure	1.8 bar		
Tank capacity	8 liters		
Chain	5/8 x 1/4"		
Optional sprockets	48 49 50		
Battery	12V - 50Wh - EQ - 8Ah		



TIGHTENING TORQUES	MX/EN/SMK	SMR	
Front wheel pin flange nut	M20x1,5	M20x1,5	70 Nm
Front brake caliper fixing screw	M8	M10	30 Nm/40 Nm
Front brake disc fixing screw	M6 cl. 10,9	M6 cl. 10,9	15 Nm
Rear brake disc fixing screw	M6 cl. 10,9	M6 cl. 10,9	15 Nm
Top fork head tightening screw	M8	M8	20 Nm
Bottom fork head tightening screw	M8	M8	20 Nm
KYB fork shoe tightening screw	M6	M6	12 Nm
Rear wheel pin flange nut	M22x1,5	M22x1,5	90 Nm
Swingarm pin flange nut	M16x1,5	M16x1,5	70 Nm
Handlebar tightening covers screws	M8	M8	20 Nm
Nut for elastic support to the handlebar	M10	M10	35 Nm
Top shock absorber nut	M10x1,25	M10x1,25	40 Nm
Bottom shock absorber screw	M10x1,25	M10x1,25	35 Nm + Loctite
Crown gear nuts	M8	M8	30 Nm
Rear brake pedal registry nut	M6	M6	15 Nm
Engine fixing screw	M10	M10	40 Nm
Generic chassis screws	M6	M6	10 Nm
	M8 M10	M8 M10	25 Nm 45 Nm
Generic chassis nuts	M6 M8 M10	M6 M8 M10	15 Nm 30 Nm 50 Nm

ENGINE TIGHTENING TORQUES			
Carter Allen screw, transmission torque, clutch torque, ignition torque	M 5	8 Nm	
Oil drain screw cap	M14x1.5	25 Nm	
Oil load screw cap	M14x1.5	25 Nm	
Base-cylinder tightening flange nuts	M 10	50 Nm	
Water pump cover Allen screw	M 5	8 Nm	
Water pump rotor	M 6	Loctite 243 + 15 Nm	
Clutch hub nut	M14x1.5	Loctite 243 + 90 Nm	
Clutch springs screw	M 6	10 Nm	
Ignition stator Allen screw	SMK/MX M 4 o EN M 5	Loctite 243 + 60 Nm	
Limit switch plate fixing countersunk screw	M 6	10 Nm	
Allen screw for gear blocker	M 6	Loctite 243 + 10 Nm	
Generic screws/nuts	M 5	8 Nm	
Generic screws/nuts	M 6	10 Nm	
Generic screws/nuts	M 8	25 Nm	
Camshafts caps screws	M 6	11 Nm	

4-STROKE - EN —





LUBRICATION			
Engine oil 250/300/450	Motorex Cross Power 4T SAE 10W-50		
Clutch Oil	DOT 4		
Brakes Oil	DOT 4		
Radiator liquid	Motorex Coolant M5.0 ready to use		







7. WIRING DIAGRAMS











ENGINE WIRING DIAGRAM (250-300-450-530 EN)



7 • WIRING DIAGRAMS



ENGINE WIRING DIAGRAM (530-450 SMR)







ALPHABETICAL INDEX

<u>A</u>	
Absorber spring	4•70
Accelerating, shifting gears, slowing down	
Accessory fuse (EN/SMR)	
Adapting fork basic calibration	
Adapting shock absorber basic calibration	
Adjusting idle speed	
Adjusting the height of the front headlamp	
Adjusting the rear-view mirrors	
Adjusting the stroke	
Adjusting throttle control cables	
ALPHABETICAL INDEX	
_	
<u>B</u>	
Basic indications for TM disc brakes	
Battery Bleeding the hydraulic clutch	
Bleeding the telescopic fork	
Brake and clutch fluid	
Braking	
BREMBO 16x18 RADIAL front BRAke PUMP (SMK)	
BREMBO 16x18 radial pump Front brake lever (smK)	
BREMBO front brake PUMP	4•80
BREMBO pump front brake lever	
BREMBO RADIAL front brake PUMP (SMR)	
BREMBO radial pump front brake levER (SMR)	2•23
С	
<u>C</u> Caltool Manual	5•117
-	
Caltool Manual	4
Carbon monoxide	4 4•75 4•76
Carbon Manual	44•754•764•84
Caltool Manual	4 4•75 4•76 4•84 4•107
Caltool Manual	4 4•754•764•844•107
Caltool Manual	4 4 • 75 4 • 76 4 • 84 4 • 107 4 • 109 4 • 95
Caltool Manual	

Cold start device (250 - 300 EN-SMR / MX / SMK)	2•24 •116 2•19 5
Danger of burns	•111 2•28 2•25 4•95 4•89 4•90 2•29 7 2•25
E EN - SMR 450 ES FI MAINTENANCE TABLE	•106 1•17 2•27 •131 •138 •143
Fork compression adjustment	4•66 1•17 5 2•38
G Gear shifting pedal General safety regulations	
HOT STATE HYDRAULIC CLUTCH PUMP.	2•23
I Idle adjustment knob	9 3•43
Kick starter Kick start in the event of a fall Kick start of the motorcycle.	3 • 50

8 • ALPHABETICAL INDEX



<u>L</u>	
Led headlight for models (en/smr)	4•97
LED taillight (EN/SMR)	
Left-hand side main components topography	
Lithium iron phosphate battery	
Lubrication	
Lubrication	0-133
<u>M</u>	
MAINTENANCE	
Mounting/dismounting of rider	
MX - SMK 450 ES FI MAINTENANCE TABLE	4•63
MX 250 - 300 ES Fi / SMK 250 MAINTENANCE TABLE	4•59
MX 250 - 300 ES FI MAINTENANCE TABLE	
_	
<u>0</u>	
Oil circuit (250 - 300)	4•105
Oil circuit (450)	4•105
P	
Precautions for winter use	2.52
Preliminary checks	
Prohibited operations	6
<u>R</u>	
Rear brake pedal	2•37
Rear suspension linkage	4•74
Recharge fuse	
Recognizing tm racing motorcycle models	
Recommended operations	
Removing the airbox	
Removing the seat	
Replacing exhaust silencer packing material	
Replacing front brake pads	
Replacing front headlight	
Replacing rear brake pads	
Right-hand side main components topography	2•21
Running-in instructions	3•44
<u>S</u>	
Safety regulations	
Serial number	
Setting off	
Shock absorber compression adjustment	4•68
Shock absorber rebound adjustment	4•69
Side stand	2•38
Software user guide	5•121
Standard adjustment	
Standard adjustment	
Standard adjustment	
Standard adjustment	
Standard adjustment	
Start-up after winter	
Start-up of the motorcycle with electrical starter	
Start engine button (MX E.S. / SMX E.S. / EN)	
Starter switch (SMR)	
Start with flooded engine	
Steering lock (EN/SMR)	2•37
Stopping and parking	3•52
Storage	
Structure of the manual	

Ţ	
TECHNICAL DATA - ENGINE FT 450	6•134
TECHNICAL DATA	
TECHNICAL DATA ENGINE MX 250 - 300 - 450	6•132
TECHNICAL DATA ENGINE SMK 250 - 300 - 450	6•133
TENSIONING the chain	4•75
Throttle	2•24
Tightening torques	6•138
Tire pressure	
Topping up brake fluid	4•81
Transporting the motorcycle	7
turn signal (EN/SMR)	
TYPE APPROVAL (EN-SMR)	7
<u>U</u> Used engine oil and gearbox oil	5
<u>V</u>	
Varying pre-load and replacing fork springs	
VEHICLE IDENTIFICATION	
Version	1 /
W	
Washing	
Weight of the rider	4• 71
WIRING DIAGRAMS	



© TM MOTO S.R.L.

Via Fano, 6 - 61122 Pesaro - Italy Tel. +39 0721 25113 - Fax +39 0721 401808